Canon

IXUS 1000 HS

Camera User Guide

- Make sure you read this guide, including the “Safety Precautions” section, before using the camera.
- Store this guide safely so that you can use it in the future.

ENGLISH

Downloaded From camera-usermanual.com Canon Manuals

Checking the Package Contents

Check if the following items are included in your camera package.
If anything is missing, contact the retailer from which you purchased the camera.

Camera



Battery Pack NB-9L
(with Terminal Cover)

Battery Charger
CB-2LB/CB-2LBE



Interface Cable
IFC-400PCU

Stereo AV Cable
AVC-DC400ST

Wrist Strap
WS-DC7

Getting Started

DIGITAL CAMERA
Solution Disk

Warranty System
Booklet

Using the Manuals

Also refer to the manuals on the DIGITAL CAMERA Manuals Disk.

- **Camera User Guide (This Guide)**
  Once you have mastered the basics, use the camera's many features to shoot more challenging photos.
- **Personal Printing Guide**
  Read when you want to connect the camera to a printer (sold separately) and print.
- **Software Guide**
  Read when you want to use the included software.

- A memory card is not included.
- Adobe Reader is required to view the PDF manuals. Microsoft Word/ Word Viewer can be installed to view the Word manuals (required only for manuals for the Middle East).

Downloaded From camera-usermanual.com Canon Manuals

Test Shots and Disclaimer

Take some initial test shots and play them back to make sure the images were recorded correctly. Please note that Canon Inc., its subsidiaries and affiliates, and its distributors are not liable for any consequential damages arising from any malfunction of a camera or accessory, including memory cards, that results in the failure of an image to be recorded or to be recorded in a way that is machine readable.

Warning Against Copyright Infringement

The images recorded with this camera are intended for personal use. Do not record images that infringe upon copyright laws without the prior permission of the copyright holder. Please be advised that in certain cases the copying of images from performances, exhibitions, or commercial properties by means of a camera or other device may contravene copyright or other legal rights even if the image was shot for personal use.

Warranty Limitations

For information on your camera's warranty, please refer to the Canon Warranty System Booklet supplied with your camera.
For Canon Customer Support contacts, please see the Warranty System Booklet.

LCD Monitor (Screen)

- The LCD monitor is produced with extremely high-precision manufacturing techniques. More than 99.99% of the pixels operate to specification, but occasionally non-performing pixels may appear as bright or dark dots. This is not a malfunction and has no effect on the recorded image.
- The LCD monitor may be covered with a thin plastic film for protection against scratches during shipment. If so, remove the film before using the camera.

Camera Body Temperature

Please take care when operating the camera for an extended period as the camera body may become warm. This is not a malfunction.

Downloaded From camera-usermanual.com Canon Manuals

What Do You Want to Do?

Shoot

- Shoot, leaving it to the camera to make settings 25

Take good people shots

Portraits (p. 61)

Kids and pets (p. 61)

Facial Expressions (p. 68)

At the beach (p. 62)

Against snow (p. 63)

Shoot various other scenes

Night Scene (p. 62)

Low Light (p. 62)

Foliage (p. 62)

Fireworks (p. 63)

Shoot with special effects

Super vivid colors (p. 63)

Poster Effect (p. 63)

Fish-eye Effect (p. 69)

Miniature Effect (p. 70)

- Focus on faces 25, 62, 84
- Shoot in places where I cannot use the flash (turn off the flash) 56
- Take pictures with me in them too (self-timer) 60, 66, 81
- Insert the date and time into my shots 59

Downloaded From camera-usermanual.com Canon Manuals

View



- Look at my pictures 28
- Automatically play back pictures (slideshow) 110
- Look at my pictures on a TV 115
- Look at my pictures on a computer. 33
- Quickly search pictures 108
- Erase pictures 29, 120

Shoot/View Movies



- Shoot movies 30, 98
- View movies 32
- Shoot fast moving subjects and play them back in slow motion 99

Print images



- Easily print pictures 134

Save



- Save images to a computer 33

Other Accessories



- Turn off sounds 48
- Use the camera abroad 15, 146
- Understand what is displayed on the screen 162

Downloaded From camera-usermanual.com Canon Manuals

Table of Contents

Chapters 1 – 3 explain the basic operations and frequently used functions of this camera. Chapters 4 onward explain the advanced functions, letting you learn more as you read each chapter.

Checking the Package Contents 2
Read This First 3
What Do You Want to Do? 4
Conventions Used in This Guide 9
Safety Precautions.....10

1 Getting Started.....13

Charging the Battery.....14
Compatible Memory Cards (Sold Separately) 16
Inserting the Battery.....17
Inserting the Memory Card 18
Setting the Date and Time 20
Setting the Display Language.....22
Formatting Memory Cards 23
Pressing the Shutter Button.....24
Taking Pictures (Smart Auto).....25
Viewing Images 28
Erasing Images.....29
Shooting Movies 30
Viewing Movies.....32
Transferring Images to a Computer for Viewing 33
Accessories 38
Separately Sold Accessories.....39

2 Learning More.....41

Components Guide.....42
Screen Display.....44
Indicator.....45
FUNC. Menu – Basic Operations 46
MENU – Basic Operations.....47
Changing the Sound Settings 48
Changing the Screen Brightness 49
Returning the Camera to Default Settings 50
Power Saving Function (Auto Power Down)..... 51
Clock Functions..... 51
Low Level Memory Card Formatting 52

3 Shooting with Commonly Used Functions 55

Turning the Flash Off 56
Zooming in More Closely on Subjects (Digital Zoom)..... 57
Inserting the Date and Time..... 59
Using the Self-Timer 60
Shooting in Various Conditions 61
Detecting a Smile and Shooting..... 64
Using the Wink Self-Timer 65
Using the Face Self-Timer 66
High-Speed Continuous Shooting (High-speed Burst) 67
Capturing the Best Facial Expressions (Best Image Selection)..... 68
Shoot with the Effects of a Fish-Eye Lens (Fish-eye Effect) 69
Take Shots That Look Like a Miniature Model (Miniature Effect) 70

Downloaded From camera-usermanual.com Canon Manuals

4 Choosing Settings Yourself....71

Shooting in Program AE 72
Adjusting the Brightness (Exposure Compensation) 72
Turning the Flash On 73
Changing the Focusing Range (Macro/Infinity) 73
Changing the Recording Pixel Setting (Image Size).... 74
Changing the Compression Ratio (Image Quality) 74
Changing the ISO Speed 76
Adjusting the White Balance 77
Continuous Shooting.... 78
Changing the Tone of an Image (My Colors) 79
Using the Self-Timer to Prevent Camera Shake 80
Customizing the Self-Timer.... 81
Shooting Using a TV Monitor 82
Changing the Composition with the Focus Lock.... 82

5 Getting More Out of Your Camera....83

Changing the AF Frame Mode.... 84
Magnifying the Focal Point.... 85
Shooting with the AF Lock 86
Shooting with Servo AF 86
Changing the Metering Method.... 87
Shooting with the AE Lock 88
Shooting with the FE Lock 88
Shooting with Slow Synchro 89
Correcting the Brightness and Shooting (i-Contrast).... 90
Red-Eye Correction 90
Checking for Shut Eyes.... 91
Changing the Color and Shooting ... 92
Shooting Long Exposures 95
Shooting Stitch Assist Images.... 96

6 Using Various Functions for Shooting Movies.... 97

Shooting Movies in Mode.... 98
Changing the Movie Mode 98
Shooting Super Slow Motion Movies 99
Shoot Movies That Look Like a Miniature Model (Miniature Effect) .. 99
Changing the Movie Quality 101
AE Lock/Exposure Shift.... 102
Other Shooting Functions.... 103
Playback Functions 104
Editing 105

7 Using Various Playback and Editing Functions.... 107

Quickly Searching Images.... 108
Viewing Images in Filtered Playback.... 109
Viewing Slideshows.... 110
Checking the Focus.... 112
Magnifying Images 113
Displaying Various Images (Smart Shuffle) 113
Changing Image Transitions 114
Viewing Images on a TV 115
Viewing Images on a High-Definition TV 116
Protecting Images 117
Erasing Images 120
Tagging Images as Favorites 122

Downloaded From camera-usermanual.com Canon Manuals

Organizing Images by Category (My Category) 123
Rotating Images 126
Resizing Images 127
Trimming 128
Adding Effects with the My Colors Function 129
Correcting the Brightness (i-Contrast) 130
Correcting the Red-Eye Effect 131

8 Printing 133

Printing Images 134
Printing from the Print List (DPOF) 136
Choosing Images for Printing (DPOF) 137
Print Added Images 140

9 Customizing Camera Settings 141

Changing Camera Settings 142
Changing Shooting Function Settings 147
Changing Playback Function Settings 151

10 Useful Information 153

Using Household Power 154
Using an Eye-Fi Card 155
Troubleshooting 157
List of Messages That Appear on the Screen 160
Information Displayed on the Screen 162
Handling Precautions 165
Functions Available in Each Shooting Mode 166
Menus 168
Playback Mode FUNC. Menu 171
Specifications 172
Index 175

Downloaded From camera-usermanual.com Canon Manuals

Conventions Used in This Guide

- Icons are used in the text to represent the camera buttons and switches.
- Language that displays on the screen appears inside [ ] (square brackets).
- The directional buttons, control dial, and FUNC./SET button are represented by the following icons.



- : Things you should be careful about
- : Troubleshooting tips
- : Hints for getting more out of your camera
- : Supplemental information
- (p. xx): Reference pages ("xx" stands for a page number)
- This guide assumes all functions are at their default settings.
- The various types of memory cards that can be used in this camera are collectively referred to as memory cards in this guide.

Downloaded From camera-usermanual.com Canon Manuals

Safety Precautions

- Before using the product, please ensure that you read the safety precautions described below. Always ensure that the product is used correctly.
- The safety precautions noted on the following pages are intended to prevent injuries to yourself and other persons, or damage to the equipment.
- Be sure to also check the guides included with any separately sold accessories you use.

⚠ Warning Denotes the possibility of serious injury or death.

- **Do not trigger the flash in close proximity to human eyes.**

Exposure to the intense light produced by the flash could damage eyesight.
In particular, remain at least one meter (39 inches) away from infants when using the flash.

- **Store this equipment out of the reach of children and infants.**

Strap: Putting the strap around a child's neck could result in asphyxiation.

- **Use only recommended power sources.**
- **Do not attempt to disassemble, alter or apply heat to the product.**
- **Avoid dropping or subjecting the product to severe impacts.**
- **To avoid the risk of injury, do not touch the interior of the product if it has been dropped or otherwise damaged.**
- **Stop using the product immediately if it emits smoke, a strange smell, or otherwise behaves abnormally.**
- **Do not use organic solvents such as alcohol, benzine, or thinner to clean the equipment.**
- **Do not let the product come into contact with water (e.g. sea water) or other liquids.**
- **Do not allow liquids or foreign objects to enter the camera.**

This could result in electrical shock or fire.
If liquids or foreign objects come into contact with the camera interior, immediately turn the camera power off and remove the battery.
If the battery charger becomes wet, unplug it from the outlet and consult your camera distributor or the closest Canon Customer Support Help Desk.

- **Do not play the supplied CD-ROM(s) in any CD player that does not support data CD-ROMs.**

Playing the CD-ROM(s) in an audio CD player (music player) could damage the speakers. It is also possible to suffer hearing loss from listening with headphones to the loud sounds of a CD-ROM played on a music CD player.

Downloaded From camera-usermanual.com Canon Manuals

- **Use only the recommended battery.**
- **Do not place the battery near or in direct flame.**
- **Unplug the power cord periodically and wipe away any dust and dirt that has collected on the plug, the exterior of the power outlet, and the surrounding area.**
- **Do not handle the power cord with wet hands.**
- **Do not use the equipment in a manner that exceeds the rated capacity of the electrical outlet or wiring accessories. Do not use if the power cord or plug are damaged, or not fully plugged into the outlet.**
- **Do not allow dirt or metal objects (such as pins or keys) to contact the terminals or plug.**

The battery may explode or leak, resulting in electrical shock or fire. This could cause injury and damage the surroundings. In the event that a battery leaks and the battery acid contacts eyes, mouth, skin or clothing, immediately flush with water.

⚠ Caution Denotes the possibility of injury.

- **Be careful not to bang the camera or subject it to strong impacts or shocks when hanging it by the strap.**
- **Be careful not to bump or push strongly on the lens.**

This could lead to injury or damage the camera.

- **Be careful not to subject the screen to strong impacts.**

If the screen cracks, injury may result from the broken fragments.

- **When using the flash, be careful not to cover it with your fingers or clothing.**

This could result in burns or damage to the flash.

- **Avoid using, placing or storing the product in the following places.**
  - **Places subject to strong sunlight.**
  - **Places subject to temperatures above 40 °C (104 °F).**
  - **Humid or dusty areas.**

These could cause leakage, overheating or an explosion of the battery, resulting in electrical shock, fire, burns or other injuries.
High temperatures may cause deformation of the camera or battery charger casing.

- **The slideshow transition effects may cause discomfort when viewed for prolonged periods.**

Downloaded From camera-usermanual.com Canon Manuals

Caution Denotes the possibility of damage to the equipment.

- **Do not aim the camera at bright light sources (the sun, etc.).**

Doing so may damage the image sensor.

- **When using the camera on a beach or at a windy location, be careful not to allow dust or sand to enter the camera.**

This may cause the camera to malfunction.

- **In regular use, small amounts of smoke may be emitted from the flash.**

This is due to the high intensity of the flash burning dust and foreign materials stuck to the front of the unit. Please use a cotton swab to remove dirt, dust or other foreign matter from the flash to prevent heat build-up and damage to the unit.

- **Remove and store the battery when you are not using the camera.**

If the battery is left inside the camera, damage caused by leakage may occur.

- **Before you discard the battery, cover the terminals with tape or other insulators.**

Contacting other metal materials may lead to fire or explosions.

- **Unplug the battery charger from the power outlet after charging is complete, or when you are not using it.**
- **Do not place anything, such as cloth on top of the battery charger while it is charging.**

Leaving the unit plugged in for a long period of time may cause it to overheat and distort, resulting in fire.

- **Do not place the battery near pets.**

Pets biting the battery could cause leakage, overheating or explosion, resulting in fire or damage.

- **Do not sit down with the camera in your pocket.**

Doing so may cause malfunctions or damage the screen.

- **When putting the camera in your bag, ensure that hard objects do not come into contact with the screen.**
- **Do not attach accessories to the strap.**

Doing so may cause malfunctions or damage the screen.

Downloaded From camera-usermanual.com Canon Manuals

1

Getting Started

This chapter explains preparations before shooting, how to shoot in AUTO mode, and then how to view and erase the images you take. The latter part of this chapter explains how to shoot and view movies and transfer images to a computer.

Attaching the Strap/Holding the Camera

- Be sure to attach the supplied strap to the camera and wrap it around your wrist when shooting to avoid dropping the camera.
- Keep your arms tight against your body while holding the camera firmly by the sides. Be sure that your fingers do not block the flash.



Downloaded From camera-usermanual.com Canon Manuals

Charging the Battery

Use the included charger to charge the battery. Be sure to charge the battery as it is not charged at the time of purchase.



1 Remove the cover.



2 Insert the battery.

- Align the ▲ marks on the battery and charger, then insert the battery by sliding it in (①) and down (②).



3 Charge the battery.

- **For CB-2LB:** Flip out the plug (①) and plug the charger into a power outlet (②).
- **For CB-2LBE:** Plug the power cord into the charger, then plug the other end into a power outlet.
  - ▶ The charge lamp lights orange and charging starts.
  - ▶ The charge lamp will light green when charging has finished. Charging takes approx. 1 hour and 50 minutes.





4 Remove the battery.

- Unplug the battery charger from the power outlet, then remove the battery by sliding it in (①) and up (②).

To protect the battery and prolong its life, do not charge it for longer than 24 hours continuously.

Downloaded From camera-usermanual.com Canon Manuals

Approximate Number of Shots That Can Be Taken

Number of Shots	Approx. 150
Playback Time	Approx. 4 hrs. 30 min.

- The number of shots that can be taken is based on the Camera & Imaging Products Association (CIPA) measurement standard.
- Under some shooting conditions, the number of shots that can be taken may be less than mentioned above.

Battery Charge Indicator

An icon or message will appear on the screen indicating the battery's charge state.

Display	Summary
	Sufficient charge.
	Slightly depleted, but sufficient.
(Blinking red)	Nearly depleted. Charge the battery.
"Change the battery pack."	Depleted. Recharge the battery.

Using the battery and charger effectively

- Charge the battery on the day, or the day before, it will be used.
  Charged batteries continue to discharge naturally even if they are not used.
- How to store the battery for long periods:
  Deplete and remove the battery from the camera. Attach the terminal cover and store the battery. Storing a battery for long periods of time (about a year) without depleting it may shorten its life span or affect its performance.
- The battery charger can also be used when abroad.
  The charger can be used in regions that have 100 – 240 V (50/60 Hz) AC power. If the plug does not fit the outlet, use a commercially available plug adapter. Do not use electrical transformers for foreign travel as they will cause damage.
- The battery may develop a bulge.
  This is a normal characteristic of the battery and does not indicate a problem. However, if the battery bulges to the point where it will no longer fit into the camera, please contact a Canon Customer Support Help Desk.
- If the battery is quickly depleted even after charging, it has reached the end of its life span. Purchase a new battery.

Downloaded From camera-usermanual.com Canon Manuals

Compatible Memory Cards (Sold Separately)

- SD memory cards (2 GB and less)*
- SDHC memory cards
  (more than 2 GB, up to and including 32 GB)*
- SDXC memory cards
  (more than 32 GB)*
- MultiMediaCards
- MMCplus memory cards
- HC MMCplus memory cards
- Eye-Fi Cards

* This memory card complies with the SD standards. Some cards may not operate properly depending on the brand of card used.

Depending on your computer's OS version, SDXC memory cards may not be recognized when using a commercially available card reader. Check to make sure that your OS supports this function beforehand.

About Eye-Fi Cards

This product is not guaranteed to support Eye-Fi card functions (including wireless transfer). In case of an issue with an Eye-Fi card, please check with the card manufacturer.
Also note that an approval is required to use Eye-Fi cards in many countries or regions. Without approval, use of the card is not permitted. If it is unclear whether the card has been approved for use in the area, please check with the card manufacturer.

Downloaded From camera-usermanual.com Canon Manuals

Inserting the Battery

Insert the included battery.



1 Open the cover.

- Slide the cover (①) and open it (②).



2 Insert the battery.

- Insert the battery as shown until it locks into place with a click.
- Be sure to insert the battery in the correct direction or it will not properly lock into place.



3 Close the cover.

- Close the cover (①), and press downward as you slide it until it clicks into place (②).

Removing the Battery



- Open the cover and press the battery lock in the direction of the arrow.

▶ The battery will pop up.

Downloaded From camera-usermanual.com Canon Manuals

Inserting the Memory Card

Insert a memory card (sold separately).



1 Check the card's write-protect tab.

- If the memory card has a write-protect tab, you will not be able to record images if the tab is in the locked position. Slide the tab up until you hear a click.



2 Open the cover.

- Slide the cover (①) and open it (②).



Terminals

3 Insert the memory card.

- Insert the memory card as shown until it locks into place with a click.
- Be sure the memory card is oriented correctly. Inserting the memory card in the wrong direction could damage the camera.



4 Close the cover.

- Close the cover (①) and press downward as you slide it until it clicks into place (②).

Removing the Memory Card



- Open the cover and push the memory card in until you hear a click, then slowly release it.

▶ The memory card will pop up.

Downloaded From camera-usermanual.com Canon Manuals

What if [Memory card locked] appears on the screen?

SD, SDHC and SDXC memory cards, and Eye-Fi cards have a write-protect tab. If this tab is in the locked position, [Memory card locked] will appear on the screen and you will not be able to take or erase images.

Approximate Number of Shots per Memory Card

Memory Card	4 GB	16 GB
Number of Shots	1471	6026

- Values are based on the default settings.
- The number of shots that can be taken will vary depending on camera settings, the subject and the memory card used.

Can you check the number of shots that can be taken?

You can check the number of shots that can be taken when the camera is in a Shooting mode (p. 25).

Downloaded From camera-usermanual.com Canon Manuals

Setting the Date and Time

The Date/Time settings screen will appear the first time the camera is turned on. Since the dates and times recorded into your images are based on these settings, be sure to set them.



1 Turn on the camera.

- Press the ON/OFF button.
- ▶ The Date/Time screen will appear.



2 Set the date and time.

- Press the ◀▶ buttons to choose an option.
- Press the ▲▼ buttons or turn the dial to set a value.

3 Complete the setting.

- Press the FUNC/SET button.
- ▶ Once the date and time have been set, the Date/Time screen will close.
- Pressing the ON/OFF button will turn off the camera.

Reappearing Date/Time screen

Set the correct date and time. If you have not set the date and time, the Date/Time screen will appear each time you turn on the camera.

Daylight saving time settings

If you choose in Step 2 and press the ▲▼ buttons or turn the dial and choose , you will set the time to daylight saving (1 hour ahead).

Downloaded From camera-usermanual.com Canon Manuals

Changing the Date and Time

You can change the current date and time settings.



1 Display the menus.

- Press the MENU button.



2 Choose [Date/Time] in the tab.

- Press the ◀▶ buttons to choose the tab.
- Press the ▲▼ buttons or turn the dial to choose [Date/Time], then press the FUNC SET button.



3 Change the date and time.

- Follow Steps 2 and 3 on p. 20 to adjust the setting.
- Pressing the MENU button will close the menu.

Date/Time battery

- The camera has a built-in date/time battery (backup battery) that allows the date/time settings to be retained for about three weeks after the battery pack has been removed.
- By inserting a charged battery or connecting an AC adapter kit (sold separately, p. 39) the date/time battery can be charged in about 4 hours even if the camera is not turned on.
- If the date/time battery is depleted, the [Date/Time] menu will appear when you turn the camera on. Follow the steps on p. 20 to set the date and time.

Downloaded From camera-usermanual.com Canon Manuals

Setting the Display Language

You can change the language that displays on the screen.



1 Enter Playback mode.

- Press the ▶ button.



2 Display the settings screen.

- Press and hold the FUNC. SET button, then immediately press the MENU button.

3 Set the display language.

- Press the ▲▼◀▶ buttons or turn the dial to choose a language, then press the FUNC. SET button.
- Once the display language has been set, the settings screen will close.

What if the clock appears when the FUNC. SET button is pressed?

The clock will appear if too much time passes between pressing the FUNC. SET button and the MENU button in Step 2. If the clock appears, press the FUNC. SET button to remove the clock and repeat Step 2.

You can also change the display language by pressing the MENU button, choosing the tab, and choosing the [Language] menu item.

Downloaded From camera-usermanual.com Canon Manuals

Formatting Memory Cards

Before you use a new memory card or one that has been formatted in other devices, you should format the card with this camera.
Formatting (initializing) a memory card erases all data on the memory card. As you cannot retrieve the erased data, exercise adequate caution before formatting the memory card.
Before formatting an Eye-Fi card (p. 155), be sure to install the software contained on the card to a computer.



1 Display the menu.

- Press the MENU button.

2 Choose [Format].

- Press the ◀▶ buttons to choose the tab.
- Press the ▲▼ buttons or turn the dial to choose [Format], then press the (FUNC SET) button.



3 Choose [OK].

- Press the ◀▶ buttons or turn the dial to choose [OK], then press the (FUNC SET) button.



4 Format the memory card.

- Press the ▲▼ buttons or turn the dial to choose [OK], then press the (FUNC SET) button.
- ▶ The memory card will be formatted.



5 Complete formatting.

- ▶ When formatting ends, [Memory card formatting complete] will appear on the screen.
- Press the (FUNC SET) button.

Downloaded From camera-usermanual.com Canon Manuals

Formatting or erasing data on a memory card merely changes the file management information on the card and does not ensure its contents are completely erased. Be careful when transferring or disposing of a memory card. When disposing of a memory card, take precautions such as physically destroying the card to prevent personal information leaks.

The total capacity of the memory card displayed in the formatting screen may be less than indicated on the memory card.

Pressing the Shutter Button

To take images that are in focus, be sure to first press the shutter button lightly (halfway) to focus, then press fully to shoot.



1 Press halfway (Press lightly to focus).

- Press lightly until the camera beeps twice and AF frames appear where the camera focused.



2 Press fully (Press fully to shoot).

- ▶ The camera plays the shutter sound and takes the shot.
- Since the shot is being taken while the shutter sound plays, be careful not to move the camera.

Does the length of the shutter sound change?

- Since the time required to shoot differs according to the scene you want to take, the length of the shutter sound may change.
- If the camera or subject moves while the shutter sound is playing, the recorded image may be blurry.

If you shoot without pressing the shutter button halfway, the image may not be in focus.

Downloaded From camera-usermanual.com Canon Manuals

Taking Pictures (Smart Auto)

Since the camera can determine the subject and shooting conditions, you can let it automatically select the best settings for the scene and just shoot. The camera can also detect and focus on faces, setting the color and brightness to optimal levels.



1 Turn on the camera.

- Press the ON/OFF button.
- ▶ The start-up screen will appear.



2 Choose AUTO mode.

- Set the mode switch to AUTO.
- When you point the camera toward the subject, the camera will make a slight noise as it determines the scene.
- ▶ The icon for the determined scene will appear in the upper right of the screen.
- ▶ The camera will focus on detected faces and display frames on them.
- ▶ Black bars will appear on the left and right sides of the screen. These areas cannot be recorded when shooting.



3 Compose the shot.

- Moving the zoom lever toward [telephoto] will zoom in on your subject, making it appear larger. Moving the lever toward [wide angle] will zoom out from your subject, making it appear smaller. (The zoom bar showing the zoom position appears on the screen.)
- If you move the zoom lever all the way toward [wide angle] or [telephoto], you will zoom quickly. If you move it slightly, you will zoom slowly.



Downloaded From camera-usermanual.com Canon Manuals



4 Focus.

- Press the shutter button halfway to focus.

AF Frame

- When the camera focuses, it will beep twice and AF frames will appear where the camera focused.
  Several AF frames will appear when the camera focuses on more than one point.



5 Shoot.

- Press the shutter button fully.
- The camera will play the shutter sound and shoot. The flash will automatically fire in low light conditions.
- The image will appear on the screen for about two seconds.
- You can take a second picture even while an image is displayed by pressing the shutter button again.

What if an icon appears in the upper right of the screen?

The icon for the determined scene will appear in the upper right of the screen. For details on the icons that appear, see “Scene Icons” (p. 163).

Downloaded From camera-usermanual.com Canon Manuals

What if...

- **What if the color and brightness of the images do not turn out as expected?**
  The scene icon (p. 163) that appears on the screen may not match the actual scene. If this happens, try shooting in P mode (p. 72).
- **What if white and gray frames appear when you point the camera toward a subject?**
  When faces are detected, a white frame appears on the face of the main subject, while gray frames appear on other detected faces. The frames will follow the subjects within a certain range (p. 84).
  If the main subject moves, however, the gray frames will disappear, leaving only the white frame.
- **What if a blue frame appears when you press the shutter button halfway?**
  A blue frame appears when a moving subject is detected; the focus and exposure will continuously adjust (Servo AF).
- **What if the indicator blinks orange and flashes on the screen?**
  Attach the camera to a tripod so that the camera does not move and blur the image.
- **What if the camera does not play any sounds?**
  Pressing the MENU button while turning on the camera power will turn off all sounds except for warning sounds. To turn the sounds on, press the MENU button to choose [Mute] in the tab, then press the ◀▶ buttons to choose [Off].
- **What if the image comes out dark even if the flash fired when shooting?**
  The subject is too far away for the flash to reach. The effective flash range is approximately 30 cm – 3.5 m (12 in. – 12 ft.) at maximum wide angle (), and approximately 1.0 – 2.0 m (3.3 – 6.6 ft.) at maximum telephoto ().
- **What if the camera beeps once when the shutter button is pressed halfway?**
  Your subject may be too close. Move the zoom lever toward and hold it until the lens stops moving. The camera will be at its maximum wide angle setting and you will be able to focus on subjects that are about 1 cm (0.4 in.) or more away from the end of the lens. Move the zoom lever toward and hold it until the lens stops moving. The camera will be at its maximum telephoto setting and you will be able to focus on subjects that are about 1 m (3.3 ft.) or more away from the end of the lens.
- **What if the lamp lights when the shutter button is pressed halfway?**
  To reduce red-eye and to assist in focusing, the lamp may light when shooting in dark areas.
- **What if the icon blinks when you try to shoot?**
  The flash is charging. You can shoot when recharging ends.

Downloaded From camera-usermanual.com Canon Manuals

Viewing Images

You can view the images you have taken on the screen.

1 Enter Playback mode.

- Press the ▶ button.

▶ The last image you took will appear.



2 Choose an image.

- Pressing ◀ or turning the dial counter-clockwise will cycle through the images in the reverse order they were taken, from the newest image to the oldest.
- Pressing ▶ or turning the dial clockwise will cycle through images in the order they were taken, from oldest to newest.
- The images change more quickly if you keep the ◀▶ buttons pressed, but they will appear coarse.
- The lens will retract after approximately 1 minute elapses.
- Pressing the ▶ button again while the lens is retracted will turn off the power.

Switching to Shooting mode

- Pressing the shutter button halfway while in Playback mode switches the camera to Shooting mode.

Downloaded From camera-usermanual.com Canon Manuals

Erasing Images

You can choose and erase images one at a time. Please note that erased images cannot be recovered. Exercise adequate caution before erasing an image.

1 Enter Playback mode.

- Press the [▶] button.
- ▶ The last image you took will appear.

2 Choose an image to erase.

- Press the ◀▶ buttons or turn the dial to display an image to erase.



3 Erase the image.

- After pressing the (FUNC SET) button, press ▲▼ buttons or turn the dial to choose 🗑, then press the (FUNC SET) button again.
- ▶ [Erase?] appears on the screen.



- Press the ◀▶ buttons or turn the dial to choose [Erase], then press the (FUNC SET) button.
- ▶ The displayed image will be erased.
- To exit instead of erasing, press the ◀▶ buttons or turn the dial to choose [Cancel], then press the (FUNC SET) button.



Downloaded From camera-usermanual.com Canon Manuals

Shooting Movies

The camera can automatically select all settings so that you can shoot movies just by pressing the movie button. The audio will record in stereo.
If you continue shooting for a long time, the camera may become warm. This is not a malfunction.



1 Choose AUTO mode.

- Set the mode switch to AUTO.

Remaining Time



2 Compose the shot.

- Moving the zoom lever toward [🔔] will zoom in on your subject, making it appear larger. Moving the lever toward [▮▮▮] will zoom out from your subject, making it appear smaller.

3 Shoot.

- Press the movie button.

Elapsed Time



- ▶ The camera will beep once, recording will start, and [● Rec] and the elapsed time will appear on the screen.
- Once shooting begins, take your finger off the movie button.
- If you change the composition of your shot during shooting, the focus, brightness and tone will automatically adjust.

Downloaded From camera-usermanual.com Canon Manuals



Microphone

- Do not touch the microphone while shooting.
- Do not press any buttons other than the movie button while shooting. The sound the buttons make will be recorded in the movie.

4 Stop shooting.

- Press the movie button again.
- ▶ The camera will beep twice and stop shooting the movie.
- ▶ The movie will record to the memory card.
- ▶ Shooting will automatically stop when the memory card fills.

Magnifying the subject while shooting

Pressing the zoom lever while shooting will zoom in on or out from the subject. However, operation sounds will be recorded.

When the mode switch is set to AUTO, the icon for the determined scene will appear (p. 163). “When Moving” icons and "With Strong Facial Shadows" icons will not appear, however. Under certain conditions, the icon that appears may not match the actual scene.

- If you change the composition while shooting so the optimum white balance is not possible, press the Movie button to stop recording, then start recording again. (only when the movie quality is fixed at 1920 (p. 101))
- Movies can be shot by pressing the movie button even when the mode switch is in positions other than AUTO (p. 97).
- When the mode switch is set to , you can set each setting for shooting movies (p. 97).

Estimated Shooting Times

Memory Card	4 GB	16 GB
Shooting Time	14 min. 34 sec.	59 min. 40 sec.

- Shooting times are based on default settings.
- Maximum clip length is approx. 10 minutes.
- Recording may stop even if the maximum clip length has not been reached on some memory cards. SD Speed Class 6 or higher memory cards are recommended.

Downloaded From camera-usermanual.com Canon Manuals

Viewing Movies

You can view the movies you have shot on the screen.



1 Enter Playback mode.

- Press the [▶] button.
- ▶ The last image you took will appear.
- ▶ [SET] appears on movies.

2 Choose a movie.

- Press the ◀▶ buttons or turn the dial to choose a movie, then press the (FUNC. SET) button.

3 Play the movie.

- Press the ▲▼ buttons or turn the dial to choose ▶ (Play), then press the (FUNC. SET) button.
- ▶ The movie will play.
- If you press the (FUNC. SET) button, the movie will pause and the movie control panel will appear. Press the ◀▶ buttons or turn the dial to choose ▶ (Play), then press the (FUNC. SET) button to resume playback.
- Press the ▲▼ buttons to adjust the volume.
- ▶ After the movie finishes, [SET] appears.

Downloaded From camera-usermanual.com Canon Manuals

What if you can't play back movies on a computer?

- Install the included software (p. 34).
- When watching a movie on a computer, frames may drop, it may not play smoothly, and the audio may stop suddenly depending on the computer's capabilities.
- If you use the supplied software to copy the movie back onto the memory card, you can play back the movie smoothly with the camera. For enhanced playback you can also connect the camera to a TV.

Transferring Images to a Computer for Viewing

You can use the included software to transfer images you have shot with the camera to a computer for viewing. If you are already using software included with another Canon-brand compact digital camera, install the software from the included CD-ROM, overwriting your current installation.

System Requirements

Windows

OS	Windows 7 Windows Vista Service Pack 1 and 2 Windows XP Service Pack 3
Computer model	The above OS should be pre-installed on computers with built-in USB ports.
CPU	Pentium 1.3 GHz or higher (still images), Core2 Duo 2.6 GHz or higher (movies)
RAM	Windows 7 (64 bit): 2 GB or more Windows 7 (32 bit), Windows Vista (64 bit, 32 bit): 1 GB or more (still images), 2 GB or more (movies) Windows XP: 512 MB or more (still images), 2 GB or more (movies)
Interface	USB
Free Hard Disk Space	ZoomBrowser EX: 200 MB or more CameraWindow: 150 MB or more* PhotoStitch: 40 MB or more
Display	1,024 x 768 pixels or higher

* For Windows XP, Microsoft .NET Framework 3.0 or later (max. 500 MB) must be installed. Installation may take some time depending on your computer's capabilities.

Downloaded From camera-usermanual.com Canon Manuals

Macintosh

OS	Mac OS X (v10.4 – v10.6)
Computer model	The above OS should be pre-installed on computers with built-in USB ports.
CPU	PowerPC G4/G5 or Intel Processor (still images), Core 2 Duo 2.6 GHz or higher (movies)
RAM	Mac OS X v10.4 – v10.5: 512 MB or more (still images), 2 GB or more (movies) Mac OS X v10.6: 1 GB or more (still images), 2 GB or more (movies)
Interface	USB
Free Hard Disk Space	ImageBrowser: 250 MB or more CameraWindow: 150 MB or more PhotoStitch: 50 MB or more
Display	1,024 x 768 pixels or higher

Preparations

Windows Vista and Mac OS X (v10.5) are used for these explanations.

1 Install the Software.

Windows

① Place the CD in the computer's CD-ROM drive.

- Place the supplied CD-ROM (DIGITAL CAMERA Solution Disk) (p. 2) into the computer's CD-ROM drive.

② Begin installation.

- Click [Easy Installation] and follow the on-screen instructions to proceed with the installation.
- If the [User Account Control] window appears, follow the on-screen instructions to proceed.

Downloaded From camera-usermanual.com Canon Manuals



③ When the installation finishes, click [Restart] or [Finish].

④ Remove the CD-ROM.

- Remove the CD-ROM when your desktop screen appears.

Macintosh

① Place the CD in the computer's CD-ROM drive.

- Place the supplied CD-ROM (DIGITAL CAMERA Solution Disk) (p. 2) into the computer's CD-ROM drive.

② Begin installation.

- Double-click the on the CD.
- Click [Install], and follow the on-screen instructions to proceed with the installation.



② Connect the camera to the computer.

- Turn off the camera.
- Open the cover and insert the small plug of the included interface cable (p. 2) firmly into the camera terminal in the direction shown.
- Insert the interface cable's larger plug into the computer. For connection details, refer to the user guide provided with the computer.



Downloaded From camera-usermanual.com Canon Manuals

3 Turn on the camera.

- Press the ▶ button to turn on the camera.

4 Open CameraWindow.

Windows

- Click [Downloads Images From Canon Camera using Canon CameraWindow].
- ▶ CameraWindow will appear.
- If CameraWindow does not appear, click the [Start] menu and choose [All Programs], followed by [Canon Utilities], [CameraWindow] and [CameraWindow].

Macintosh

- ▶ CameraWindow will appear when you establish a connection between the camera and computer.
- If CameraWindow does not appear, click the CameraWindow icon on the Dock (the bar which appears at the bottom of the desktop).

For Windows 7, use the following steps to display CameraWindow.

① Click on the task bar.
② In the screen that appears, click the link to modify the program.
③ Choose [Downloads Images From Canon Camera using Canon CameraWindow] and click [OK].
④ Double click .

Downloaded From camera-usermanual.com Canon Manuals

Transfer and View Images



- Click [Import Images from Camera], and then click [Import Untransferred Images].
- ▶ All images not previously transferred will transfer to the computer. Transferred images will be sorted by date and saved in separate folders in the Pictures folder.
- When [Image import complete.] appears, click [OK], then click [X] to close CameraWindow.
- Turn off the camera and unplug the cable.
- For details on how to view images using a computer, refer to the *Software Guide*.

You can transfer images even without using the image transfer function in the included software by simply connecting your camera to a computer. There are, however, the following limitations.

- It may take a few minutes from when you connect the camera to the computer until you can transfer images.
- Images shot in the vertical orientation may be transferred in the horizontal orientation.
- Protection settings for images may be lost when transferred to a computer.
- There may be problems transferring images or image information correctly depending on the version of the operating system in use, the file size, or the software in use.
- Some functions in the included software may not be available, such as editing movies, and transferring images to the camera.

Downloaded From camera-usermanual.com Canon Manuals

Accessories



Downloaded From camera-usermanual.com Canon Manuals

Separately Sold Accessories

The following camera accessories are sold separately. Some accessories are not sold in some regions, or may no longer be available.

Power Supplies

Battery Charger CB-2LB/CB-2LBE

- An adapter for charging Battery Pack NB-9L.



Battery Pack NB-9L

- Rechargeable lithium-ion battery.



AC Adapter Kit ACK-DC70

- This kit lets you power the camera using household power. Recommended for powering the camera for an extended period of time or when connecting to a computer or printer. Cannot be used to charge the camera battery.

Using Accessories Abroad

The battery charger and the AC adapter kit can be used in regions that have 100 – 240 V (50/60 Hz) AC power.
If the plug does not fit the outlet, use a commercially available plug adapter.
Do not use electrical transformers for foreign travel as they will cause damage.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO LOCAL REGULATION.

Downloaded From camera-usermanual.com Canon Manuals

Flash

High-Power Flash HF-DC1

- This externally mounted flash can be used to capture photographic subjects that are too distant for the built-in flash to illuminate.

Other Accessories

HDMI Cable HTC-100

- Use this cable to connect the camera to the HDMI™ terminal on a high-definition TV set.

Printers



SELPHY series

Inkjet Printers

Canon-Brand PictBridge Compliant Printers

- By connecting your camera to a Canon-brand PictBridge compliant printer, you can print your images without having to use a computer.
  For more information, visit your nearest Canon retailer.

Use of genuine Canon accessories is recommended.

This product is designed to achieve excellent performance when used with genuine Canon accessories. Canon shall not be liable for any damage to this product and/or accidents such as fire, etc., caused by the malfunction of non-genuine Canon accessories (e.g., a leakage and/or explosion of a battery pack). Please note that this warranty does not apply to repairs arising out of the malfunction of non-genuine Canon accessories, although you may request such repairs on a chargeable basis.

Downloaded From camera-usermanual.com Canon Manuals

2

Learning More

This chapter explains the parts of the camera and what appears on the screen, as well as the basic operating instructions.

Downloaded From camera-usermanual.com Canon Manuals





① Lamp (pp. 60, 66, 80, 81, 147)
② Lens
③ Zoom Lever
Shooting: (Telephoto) / (Wide Angle) (pp. 25, 30, 57)
Playback: (Magnify) / (Index) (pp. 108, 113)
④ Shutter Button (p. 24)
⑤ ON/OFF button (p. 20)
⑥ Mode Switch
⑦ Flash (pp. 56, 73)
⑧ Speaker
⑨ Microphone (p. 31)
⑩ Battery Cover (p. 17)
⑪ DC Coupler Terminal Cover (p. 154)
⑫ Tripod Socket
⑬ Memory Card Slot Cover (p. 18)
⑭ Strap Mount (p. 13)

Mode Switch

Use the mode switch to change the Shooting mode.



For shooting movies (pp. 30, 97).

You can leave it to the camera to select settings for fully automatic shooting (p. 25).

You can shoot with the best settings for the scene (p. 61) or choose settings yourself to take various types of pictures (pp. 55, 71, 83).

Downloaded From camera-usermanual.com Canon Manuals





① Screen (LCD Monitor) (pp. 44, 162, 164)
② Indicator (p. 45)
③ Movie Button (pp. 30, 97)
④ A/V OUT (Audio/Video Output) / DIGITAL Terminal (pp. 35, 115, 134)
⑤ HDMI Terminal (p. 116)
⑥ MENU Button (p. 47)
⑦ ▶ (Playback) Button (pp. 28, 32, 107)
⑧ (Self-Timer) (p. 60) / ▲ Button
⑨ (Focus Range) (p. 73) / ◀ Button
⑩ Control Dial (p. 43)
⑪ FUNC./SET (Function/Set) Button (p. 46)
⑫ (Flash) (pp. 56, 73) / ▶ Button
⑬ DISP. (Display) (p. 44) / ▼ Button

Control Dial



Turning the control dial allows you to perform operations such as choosing items or switching images. Except for a few operations, the same operations are possible with the ▲▼◀▶ buttons.

If you touch the control dial in a Shooting mode, the function assigned to the position you touch will appear on the screen. When you switch to Playback mode, the function assigned to the dial in Playback mode will appear for a few seconds.

Downloaded From camera-usermanual.com Canon Manuals

Screen Display

Switching the Display

You can change the screen display using the ▼ button. Refer to p. 162 for details on information that appears on the screen.

Shooting



Information Display | No Information Display

Playback



No Information Display | Simple Information Display | Detailed Information Display | Focus Check Display (p. 112)

You can also switch the display by pressing the ▼ button while the image displays right after shooting. However, Simple Information Display is not available. You can change the display that appears first by pressing the MENU button, then choosing [Review info] in the 📷 tab (p. 149).

Downloaded From camera-usermanual.com Canon Manuals

Screen Display in Dark Shooting Conditions

The display automatically brightens when shooting in dark conditions, allowing you to check the composition (Night Display function). However, the brightness of the image on the screen, and the brightness of the actual image recorded may be different. Screen noise may appear and the movement of the subject may appear somewhat jagged on the screen. This has no effect on the recorded image.

Overexposure Warning during Playback

In “Detailed Information Display” (p. 44), overexposed areas of the image flash on the screen.

Histogram during Playback



- The graph that appears in “Detailed Information Display” (p. 164) is called the histogram. The histogram shows the distribution of brightness in an image horizontally, and the amount of brightness vertically. When the graph approaches the right side, the image is bright, but when it approaches the left side, the image is dark, and in this way you can judge the exposure.

Indicator

The indicator on the back of the camera (p. 43) will light or blink depending on the camera’s status.

Colors	Status	Operation Status
Green	Lights	Shooting preparation complete/Display off (p. 145)
	Blinks	Recording/reading/transmitting image data
Orange	Lights	Shooting preparation complete (flash on)
	Blinks	Camera shake warning (pp. 27, 56)

When the indicator blinks green, data is being recorded/read or various information is being transmitted. Do not turn off the power, open the memory card slot cover/battery cover, shake or jolt the camera. These actions may corrupt the image data or cause the camera or memory card to malfunction.

Downloaded From camera-usermanual.com Canon Manuals

FUNC. Menu – Basic Operations

Commonly used functions can be set with the FUNC. menu.
The menu items and options differ depending on the Shooting mode and Playback mode (pp. 166 – 169).

1 Display the FUNC. menu.

- Press the (FUNC SET) button.

2 Choose a menu item.

- Press the ▲▼ buttons or turn the dial to choose a menu item, then press the (FUNC SET) or ▶ button.
- Choosing some menu items changes the screen to display further menu options.

3 Choose an option.

- Press the ▲▼ buttons or turn the dial to choose an option.
- You can also choose settings by pressing the MENU button on options that display (MENU).
- To return to the menu item, press the ◀ button.

4 Complete the setting.

- Press the (FUNC SET) button.
- ▶ The shooting screen will reappear and the setting you chose will display on the screen.

Downloaded From camera-usermanual.com Canon Manuals

MENU – Basic Operations

Various functions can be set from the menus. The menu items are organized under tabs, such as for shooting (📷) and playback (▶). The options differ depending on the Shooting mode and the Playback mode (pp. 168 – 171).



1 Display the menu.

- Press the MENU button.

2 Choose a tab.

- Press the ◀▶ buttons, or move the zoom lever left or right to choose a tab.

3 Choose an item.

- Press the ▲▼ buttons or turn the dial to choose an item.
- Some items require you to press the (FUNC. SET) or ▶ button to display a submenu in which you change the setting.

4 Choose an option.

- Press the ◀▶ buttons to choose an option.



5 Complete the setting.

- Press the MENU button to restore the normal screen.

Downloaded From camera-usermanual.com Canon Manuals

Changing the Sound Settings

You can silence or adjust the volume of camera sounds.

Muting Sounds



1 Display the menu.

- Press the MENU button.

2 Choose [Mute].

- Press the ◀▶ buttons to choose the tab.
- Press the ▲▼ buttons or turn the dial to choose [Mute], then press the ◀▶ buttons to choose [On].
- Press the MENU button to restore the normal screen.

You can also mute camera sounds by holding down the ▼ button and turning on the power.

Adjusting the Volume



1 Display the menu.

- Press the MENU button.

2 Choose [Volume].

- Press the ◀▶ buttons to choose the tab.
- Press the ▲▼ buttons or turn the dial to choose [Volume], then press the FUNC SET button.

3 Change the volume.

- Press the ▲▼ buttons or turn the dial to choose an item, then press the ◀▶ buttons to adjust the volume.
- Press the MENU button twice to restore the normal screen.

Downloaded From camera-usermanual.com Canon Manuals

Changing the Screen Brightness

The screen brightness can be changed in two ways.

Using the Menu



1 Display the menu.

- Press the MENU button.

2 Choose [LCD Brightness].

- Press the ◀▶ buttons to choose the tab.
- Press the ▲▼ buttons or turn the dial to choose [LCD Brightness].

3 Change the brightness.

- Press the ◀▶ buttons to change the brightness.
- Press the MENU button twice to restore the normal screen.

Using the ▼ Button

- Press the ▼ button for more than one second.
- ▶ The screen increases to maximum brightness regardless of the setting in the tab.
- Pressing the ▼ button again for more than one second will return the screen to the original brightness.

- The next time you turn on the camera, the screen will be at the brightness setting chosen in the tab.
- When you have set the brightness to its highest setting in the tab, you cannot change the brightness with the ▼ button.

Downloaded From camera-usermanual.com Canon Manuals

Returning the Camera to Default Settings

When you have mistakenly changed a setting, you can reset the camera to the default settings.





1 Display the menu.

- Press the MENU button.

2 Choose [Reset All].

- Press the ◀▶ buttons to choose the tab.
- Press the ▲▼ buttons or turn the dial to choose [Reset All], then press the (FUNC SET) button.

3 Reset the settings.

- Press the ◀▶ buttons or turn the dial to choose [OK], then press the (FUNC SET) button.
- ▶ The camera will reset to the default settings.

Are there functions that cannot be reset?

- The [Date/Time] (p. 21) in the tab, [Language] (p. 22), [Video System] (p. 115), [Time Zone] (p. 146), and the image registered in [Start-up Image] (p. 143).
- The saved data for custom white balance (p. 77).
- Colors that were chosen in Color Accent (p. 92) or Color Swap (p. 93).
- Shooting modes set with the mode switch set to or (pp. 61, 98).

Downloaded From camera-usermanual.com Canon Manuals

Power Saving Function (Auto Power Down)

To save battery power, the screen turns off, and the camera shuts down automatically when it is not operated for a certain time.

Power Saving during Shooting

The screen will turn off approximately 1 minute after the camera is last operated. After about 2 more minutes, the lens will retract and the power will turn off. When the screen has turned off but the lens has not yet retracted, pressing the shutter button halfway (p. 24) turns on the screen and shooting can continue.

Power Saving during Playback

The power will turn off approximately 5 minutes after the camera is last operated.

- You can turn off the power saving function (p. 145).
- You can adjust the time before the screen turns off (p. 145).

Clock Functions

You can check the current time.

- Press and hold the (FUNC SET) button.
- ▶ The current time appears.
- If you hold the camera vertically while using the clock function, it will switch to vertical display. Press the ◀▶ buttons or turn the dial to change the display color.
- Press the (FUNC SET) button again to cancel the clock display.

When the camera power is off, press and hold the (FUNC SET) button, then press the ON/OFF button to display the clock.

Downloaded From camera-usermanual.com Canon Manuals

Low Level Memory Card Formatting

Perform low level formatting when [Memory card error] appears, the camera does not operate properly, or you think that the recording/reading speed of a memory card has dropped. As you cannot retrieve the erased data, exercise adequate caution before formatting the memory card.



1 Display the menu.

- Press the MENU button.

2 Choose [Format].

- Press the ◀▶ buttons to choose the tab.
- Press the ▲▼ buttons or turn the dial to choose [Format], then press the (FUNC. SET) button.



3 Choose [Low Level Format].

- Press the ▲▼ buttons or turn the dial to choose [Low Level Format], then press the ◀▶ buttons to display ✓.
- Press the ▲▼◀▶ buttons or turn the dial to choose [OK], then press the (FUNC. SET) button.



4 Start the low level format.

- Press the ▲▼ buttons or turn the dial to choose [OK], then press the (FUNC. SET) button.
- ▶ Low level formatting starts.
- ▶ When low level formatting ends, [Memory card formatting complete] will appear.

5 Complete the low level format.

- Press the (FUNC. SET) button.

Downloaded From camera-usermanual.com Canon Manuals

- Low level formatting may take longer than standard formatting (p. 23), since all recorded data is erased.
- You can stop a low level format of a memory card by choosing [Stop]. When stopping low level formatting, the data will be erased but the memory card can be used without problem.

Downloaded From camera-usermanual.com Canon Manuals

Downloaded From camera-usermanual.com Canon Manuals

3

Shooting with Commonly Used Functions

This chapter explains how to shoot in different conditions, as well as how to use common functions, such as the self-timer, and turn off the flash.

- This chapter assumes the camera is set to AUTO mode for “Turning the Flash Off” (p. 56) to “Using the Self-Timer” (p. 60). When shooting in a mode other than AUTO, check which functions are available in that mode (pp. 166 – 167).
- “Shooting in Various Conditions” (p. 61) to “Take Shots That Look Like a Miniature Model (Miniature Effect)” (p. 70) assumes that the corresponding mode has been chosen.

Downloaded From camera-usermanual.com Canon Manuals

Turning the Flash Off

You can shoot with the flash turned off.



1 Press the ▶ button.

2 Choose ⚡.

- Press the ◀▶ buttons or turn the ◎ dial to choose ⚡, then press the (FUNC SET) button.
- ▶ Once set, ⚡ will appear on the screen.
- To turn the flash back on, follow the Steps above to return the setting to ⚡A.

What if the indicator blinks orange and a flashing 📳 appears?

When you press the shutter button halfway in low light conditions where camera shake is likely, the indicator will blink orange and a flashing 📳 will appear on the screen. Attach the camera to a tripod to prevent it from moving.

Downloaded From camera-usermanual.com Canon Manuals

Zooming in More Closely on Subjects (Digital Zoom)

You can use the digital zoom to zoom up to approximately 40x and capture subjects that are too far away for the optical zoom to enlarge. The images may appear coarse, however, depending on the recording pixel setting (p. 74) and the zoom factor used.



1 Move the zoom lever toward [🔍].

- Hold the lever until zooming stops.
- The zoom will stop when the largest possible zoom factor without image deterioration has been reached, and the zoom factor will appear when you release the zoom lever.



2 Move it toward [🔍] again.

- The digital zoom will zoom in even further on the subject.

What if the zoom factor appears in blue?

Images shot at zoom factors that appear in blue will be coarse.

Turning off the digital zoom

To turn off the digital zoom, press the MENU button to choose [Digital Zoom] in the 📷 tab, then choose [Off].

The focal length when using the optical zoom and digital zoom together is 36 – 1440 mm, and 36 – 360 mm when using the optical zoom alone (all focal lengths are 35mm film equivalent).

Downloaded From camera-usermanual.com Canon Manuals

Digital Tele-Converter

The focal length of the lens can be increased by approx. 1.4x or approx. 2.3x. This enables a faster shutter speed and less chance of camera shake than the zoom (including digital zoom) used by itself at the same zoom factor. The images may appear coarse, however, depending on the combination of recording pixel (p. 74) and digital tele-converter settings used.





1 Choose [Digital Zoom].

- Press the MENU button.
- Press the ◀▶ buttons to choose the 📷 tab.
- Press the ▲▼ buttons or turn the dial to choose [Digital Zoom].

2 Accept the setting.

- Press the ◀▶ buttons to choose a magnification.
- Pressing the MENU button will restore the shooting screen.
- ▶ The view will be enlarged and the zoom factor will appear on the screen.
- To return to standard digital zoom, choose [Digital Zoom] and the [Standard] option.

What if the zoom factor appears in blue?

Using this function at a recording pixel setting of L or M1 will cause image deterioration (the zoom factor will appear in blue).

- The respective focal lengths when using [1.4x] and [2.3x] are 50.4 – 504 mm and 82.8 – 828 mm (35mm film equivalent).
- The digital tele-converter cannot be used together with the digital zoom.

Downloaded From camera-usermanual.com Canon Manuals

Inserting the Date and Time

You can insert the shooting date and time in the lower right corner of an image. Once inserted, however, they cannot be deleted. Be sure to check beforehand that the date and time are correctly set (p. 20).



1 Choose [Date Stamp].

- Press the MENU button.
- Press the ◀▶ buttons to choose the 📷 tab.
- Press the ▲▼ buttons or turn the dial to choose [Date Stamp].

2 Accept the setting.

- Press the ◀▶ buttons to choose [Date] or [Date & Time].
- Pressing the MENU button will restore the shooting screen.
- ▶ Once set, [DATE] will appear on the screen.

3 Shoot.

- ▶ The shooting date or time will be recorded in the image's lower right corner.
- To restore to the original setting, choose [Off] in Step 2.

You can insert and print the shooting date in images which do not have an embedded date and time as follows. However, if you do this for images with an embedded date and time, the date and time may be printed twice.

- **Use the DPOF print settings (p. 137) to print.**
- **Use the included software to print.**
  Refer to the *Software Guide* for details.
- **Print using printer functions.**
  Refer to the *Personal Printing Guide* for details.

Downloaded From camera-usermanual.com Canon Manuals

Using the Self-Timer

The self-timer can be used to shoot a group photo that includes the photographer. The camera will shoot approximately 10 seconds after the shutter button is pressed.



1 Press the ▲ button.

2 Choose ⏲10.

- Press the ▲▼ buttons or turn the dial to choose ⏲10, then press the (FUNC SET) button.
- Once set, ⏲10 will appear on the screen.



3 Shoot.

- Press the shutter button halfway to focus on the subject, then press it fully.
- When the self-timer starts, the lamp blinks and the self-timer sound plays.
- Two seconds before the shutter releases, the lamp and sound speed up (the lamp remains lit when the flash will fire).
- To cancel shooting with the timer after countdown has started, press the ▲ button.
- To restore the original setting, choose ⏲OFF in Step 2.

You can change the delay time and number of shots (p. 81).

Downloaded From camera-usermanual.com Canon Manuals

Shooting in Various Conditions

The camera will select the necessary settings for the conditions in which you wish to shoot when you choose the matching mode.

1 Set the mode switch to 📷.

2 Choose the Shooting mode.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the ◎ dial to choose **P**, then press the (FUNC SET) button again.
- Press the ▲▼ buttons or turn the ◎ dial to choose a Shooting mode, then press the (FUNC SET) button.

3 Shoot.

Take portraits (Portrait)

- Produces a soft effect when photographing people.

Take shots of kids and pets (Kids&Pets)

- Lets you capture subjects that move around, such as children and pets, without missing photo opportunities.
- At maximum wide angle setting you will be able to focus on subjects that are about 1 m (3.3 ft.) or more away from the end of the lens, and at maximum telephoto setting you will be able to focus on subjects that are about 3 m (9.8 ft.) or more away from the end of the lens.

Downloaded From camera-usermanual.com Canon Manuals

Take nightscapes without using a tripod (Handheld NightScene)

- Lets you take beautiful snapshots of city nightscenes by combining several continuous shots to reduce camera shake and noise.
- When using a tripod, you should shoot in AUTO mode (p. 25).
- A recording pixel setting of L will display, and the image will be fixed at 3648 x 2736 pixels.

Take shots in low light conditions (Low Light)

- Lets you shoot in dark places with reduced camera shake and subject blur.
- A recording pixel setting of M will display, and the image will be fixed at 1824 x 1368 pixels.

Take shots of people at the beach (Beach)

- Lets you take shots of brightly lit people on sandy beaches where the reflected sunlight is strong.

Take shots of foliage (Foliage)

- Lets you shoot trees and leaves, such as new growth, autumn leaves or blossoms, in vivid colors.

Downloaded From camera-usermanual.com Canon Manuals

Take shots of people in snow (Snow)

- Lets you take bright, natural-colored shots of people against snowy backgrounds.

Take shots of fireworks (Fireworks)

- Lets you take shots of fireworks in vivid colors.

- In mode, attach the camera to a tripod to prevent the camera from moving and blurring the image. Additionally, you should set the [IS Mode] to [Off] when shooting with a tripod (p. 150).
- In mode, hold the camera firmly while shooting as multiple images are captured in succession.

- In or mode, images may appear coarse because the ISO speed (p. 76) is increased to match the shooting conditions.
- If camera shake is too strong while shooting in mode, the camera may not be able to combine images or you may not obtain the expected result depending on shooting conditions.

Adding Effects and Shooting

Shoot images with vivid colors (Super Vivid)

- Lets you take shots with vivid, intense colors.

Take posterized shots (Poster Effect)

- Lets you take shots that look like an old poster or illustration.

Downloaded From camera-usermanual.com Canon Manuals

Since you may not achieve the expected results with images shot in and , try taking some test shots first.

Detecting a Smile and Shooting

The camera will shoot, even without pressing the shutter button, when it detects a smile.

1 Choose .

- Follow Steps 1 – 2 on p. 61 to choose , then press the MENU button for more than one second.
- Press the ◀▶ buttons or turn the dial to choose , then press the MENU button.
- ▶ The camera will enter shooting stand-by, and [Smile Detection on] will appear on the screen.

2 Point the camera at a person.

- Each time the camera detects a smile it will shoot after the lamp lights.
- Pressing the ▲ button will pause smile detection. Press the ▲ button again to resume smile detection.

What if a smile is not detected?

Smiles are easier to detect if the subject faces the camera, and opens their mouth enough to show some teeth when smiling.

Changing the number of shots

After choosing in Step 1, press the ▲▼ buttons.

- You should switch to another mode when you finish shooting, or the camera will continue taking shots each time the camera detects a smile.
- You can also shoot by pressing the shutter button.

Downloaded From camera-usermanual.com Canon Manuals

Using the Wink Self-Timer

Point the camera at a person and press the shutter button fully. The camera will shoot approximately two seconds after it detects a wink.

1 Choose .

- Follow Steps 1 – 2 on p. 61 to choose , then press the MENU button for more than one second.
- Press the ◀▶ buttons or turn the dial to choose , then press the MENU button.

2 Compose the shot and press the shutter button halfway.

- Confirm that a green frame appears around the face of the person who will wink.



3 Press the shutter button fully.

- The camera will enter shooting stand-by, and [Wink to take picture] will appear on the screen.
- The lamp will blink and the self-timer sound will play.

4 Face the camera and wink.

- The shutter will release approximately 2 seconds after a wink is detected from the person with a frame around the person's face.
- To cancel the countdown, press the ▲ button.

What if a wink is not detected?

- Wink a bit slowly.
- A wink may not be detected if eyes are covered by hair or a hat, or when wearing glasses.

Downloaded From camera-usermanual.com Canon Manuals

Changing the number of shots

After choosing in Step 1, press the ▲▼ buttons.

- Shutting both eyes will also be detected as a wink.
- If a wink is not detected, the shutter will release approximately 15 seconds later.
- If there are no people in the shot when the shutter button is pressed fully, the camera will shoot after a person enters the shot and winks.

Using the Face Self-Timer

The shutter will release approximately two seconds after the camera detects a new face (p. 84). You can use this when the photographer wants to be in the image, such as a group photo.

1 Choose .

- Follow Steps 1 – 2 on p. 61 to choose , then press the MENU button for more than one second.
- Press the ◀▶ buttons or turn the dial to choose , then press the MENU button.

2 Compose the shot and press the shutter button halfway.

- Make sure a green frame appears on the face focused on and white frames appear on other faces.



3 Press the shutter button fully.

- The camera will enter shooting stand-by, and [Look straight at camera to start count down] will appear on the screen.
- The lamp will blink and the self-timer sound will play.

Downloaded From camera-usermanual.com Canon Manuals

4 Join the subjects and look at the camera.

- When the camera detects a new face, the lamp and sound will speed up (the lamp remains lit when the flash will fire), and two seconds later the shutter will release.
- To cancel shooting with the timer after countdown has started, press the ▲ button.

Changing the number of shots

After choosing in Step 1, press the ▲▼ buttons.

Even if your face is not detected after joining the subjects, the shutter will release approximately 15 seconds later.

High-Speed Continuous Shooting (High-speed Burst)

You can shoot continuously at a maximum speed of approximately 8.8 images/second while the shutter button is pressed fully and held. The recording pixel setting will be fixed at M (1824 x 1368 pixels).

1 Choose .

- Follow Steps 1 – 2 on p. 61 to choose .

2 Shoot.

- As long as you hold the shutter button down, the camera will shoot successive images.

- Focus, exposure and white balance settings are set with the first shot.
- Depending on the shooting conditions, camera settings and the zoom position, the shooting speed may slow down.
- As the number of images increases, the shooting speed may slow down.

Downloaded From camera-usermanual.com Canon Manuals

Capturing the Best Facial Expressions (Best Image Selection)

The camera takes five continuous shots, then detects various aspects of the shot such as facial expressions, and saves only one picture detected as the best.
The recording pixel setting will be fixed at M (1824 x 1368 pixels).

1 Choose .

- Follow Steps 1 – 2 on p. 61 to choose .

2 Shoot.

- When the shutter button is pressed fully, the camera takes five continuous shots, and saves one picture only.

- The focus, brightness and white balance will be set with the first shot.
- Depending on the shooting condition, you may not obtain the expected result.

Downloaded From camera-usermanual.com Canon Manuals

Shoot with the Effects of a Fish-Eye Lens (Fish-eye Effect)

Lets you shoot with the distorting effect of a fish-eye lens.



1 Choose .

- Follow Steps 1 – 2 on p. 61 to choose .

2 Choose an effect level.

- Press the MENU button for more than one second.
- ▶ [Effect Level] will appear on the screen.
- Press the ◀▶ buttons or turn the dial to choose an effect level, then press the MENU button.
- ▶ You can check the effect on the screen.

3 Shoot.

Since you may not achieve the expected results depending on the shooting conditions, try taking some test shots first.

Downloaded From camera-usermanual.com Canon Manuals

Take Shots That Look Like a Miniature Model (Miniature Effect)

Blurs chosen portions in the top and bottom of an image to produce the effect of a miniature model.

1 Choose 🖷.

- Follow Steps 1 – 2 on p. 61 to choose 🖷.

2 Choose the area to keep in focus.

- Press the MENU button for more than one second.
- ▶ A white frame (the area that will not be blurred) appears on the screen.
- Move the zoom lever to change the frame size, and press the ▲▼ buttons to change the frame position, then press the MENU button.

3 Shoot.

- For the screen in Step 2, pressing the ◀▶ buttons will allow you to change the frame vertical orientation and also change the area to focus in. Pressing the ▲▼ buttons will return the frame to horizontal orientation.
- Holding the camera vertically will change the orientation of the frame.
- Since you may not achieve the expected results depending on the shooting conditions, try taking some test shots first.

Downloaded From camera-usermanual.com Canon Manuals

4

Choosing Settings Yourself

In this chapter you will learn how to use the various functions in **P** mode to progressively advance your shooting skills.

- This chapter assumes that you have set the mode switch to 📷 and the camera is in **P** mode.
- **P** stands for Program AE.
- Before attempting to shoot using a function explained in this chapter in modes other than **P** mode, check if the function is available in those modes (pp. 166 – 169).

Downloaded From camera-usermanual.com Canon Manuals

Shooting in Program AE

You can choose the settings for various functions to suit your preferences. AE stands for Auto Exposure.
The focusing range is approximately 5 cm (20 in.) – infinity at maximum wide angle (), and approximately 1 m (3.3 ft.) – infinity at maximum telephoto ().

1 Enter P mode.

- Follow Steps 1 – 2 on p. 61 to choose **P**.

2 Adjust the settings according to your purposes (pp. 73 – 81).

3 Shoot.

What if the shutter speed and aperture value appear in orange?

If a correct exposure cannot be obtained when pressing the shutter button halfway, the shutter speed and aperture value are shown in orange. Try the following settings to obtain the correct exposure.

- Turn on the flash (p. 73)
- Choose a higher ISO speed (p. 76)

Adjusting the Brightness (Exposure Compensation)

You can adjust the standard exposure set by the camera in 1/3-stop increments in the range of -2 to +2.

1 Enter Exposure Compensation mode.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose ±0, then press the (FUNC SET) button again.

2 Adjust the brightness.

- While watching the screen, press the ▲▼ buttons or turn the dial to adjust the brightness, then press the (FUNC SET) button.

▶ The exposure compensation amount will appear on the screen.

Downloaded From camera-usermanual.com Canon Manuals

Turning the Flash On

You can make the flash fire every time you shoot. The effective flash range is approximately 30 cm – 3.5 m (12 in. – 12 ft.) at maximum wide angle (), and approximately 1.0 – 2.0 m (3.3 – 6.6 ft.) at maximum telephoto ().

Choose .

- After pressing the ▶ button, press the ◀▶ buttons or turn the dial to choose , then press the (FUNC SET) button.
- ▶ Once set, will appear on the screen.

Changing the Focusing Range (Macro/Infinity)

When it is difficult to focus because your shot contains subjects that are both near and far, you can change the focusing range to focus more reliably.

Choose a focusing range.

- After pressing the ◀ button, press the ◀▶ buttons or turn the dial to choose an option, then press the (FUNC SET) button.
- ▶ The icon for the set mode will appear.

	Focusing Range	Description
	Approx. 1 – 50 cm* (0.4 in. – 1.6 ft.)	Only focuses on close subjects.
	Approx. 3 m (9.8 ft.) – infinity	Only focuses on far-away subjects.

* When at the maximum wide angle () setting of the lens.

In macro shooting, the edges of the image may darken if the flash fires.

How can I take better close-ups?

Try attaching the camera to a tripod and shooting in to prevent the camera from moving and blurring the image (p. 80).

For macro shooting, will turn gray in the area that displays in the yellow bar underneath the zoom bar, and the camera will not focus.

Downloaded From camera-usermanual.com Canon Manuals

Changing the Recording Pixel Setting (Image Size)

You can choose from five recording pixel (image size) settings.

1 Choose the recording pixel setting.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose L, then press the (FUNC SET) button again.

2 Choose an option.

- Press the ▲▼ buttons or turn the dial to choose an option, then press the (FUNC SET) button.
- ▶ The setting will appear on the screen.

- If you choose W, you cannot use Digital Zoom (p. 57) or Digital Tele-Converter (p. 58).
- If you press the movie button when the camera is set to W, the aspect ratio of the display will change and recording will begin (when set to [640] or [320] (p. 101)).

Changing the Compression Ratio (Image Quality)

You can choose from the following two compression ratios (image quality): ◢ (Fine), ▟ (Normal).



1 Choose the compression ratio setting.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose ◢, then press the (FUNC SET) button again.

2 Choose an option.

- Press the ▲▼ buttons or turn the dial to choose an option, then press the (FUNC SET) button.
- ▶ The setting will appear on the screen.

Downloaded From camera-usermanual.com Canon Manuals

Approximate Values for Recording Pixels and Compression Ratio

Recording Pixels	Compression Ratio	Single Image Data Size (Approx. KB)	Number of Shots per Memory Card	
			4 GB	16 GB
L (Large) 10M/3648x2736	◢	2565	1471	6026
	▟	1226	3017	12354
M1 (Medium 1) 6M/2816x2112	◢	1620	2320	9503
	▟	780	4641	19007
M2 (Medium 2) 2M/1600x1200	◢	558	6352	26010
	▟	278	12069	49420
S (Small) 0.3M/640x480	◢	150	20116	82367
	▟	84	30174	123550
W (Widescreen) 3648x2048	◢	1920	1978	8101
	▟	918	4022	16473

- The values in the table are measured according to Canon standards and may change depending on the subject, memory card and camera settings.

Approximate Values for Paper Size



- S Suitable for sending images as e-mail attachments.
- W For printing on wide size paper.

Downloaded From camera-usermanual.com Canon Manuals

Changing the ISO Speed

1 Choose the ISO speed.

- After pressing the (FUNC. SET) button, press the ▲▼ buttons or turn the dial to choose ISO AUTO, then press the (FUNC. SET) button again.

2 Choose an option.

- Press the ▲▼ buttons or turn the dial to choose an option, then press the (FUNC. SET) button.
- ▶ The setting will appear on the screen.

ISO AUTO	Automatically adjusts the ISO speed to the Shooting mode and shooting conditions.	
ISO 125 ISO 200	Low	Fine weather conditions, outdoor shooting.
ISO 400 ISO 800	↕	Cloudy, twilight
ISO 1600 ISO 3200	High	Nightscapes, dark interiors

Changing the ISO speed

- Lowering the ISO speed results in sharper images, but there may be an increased chance of image blurring in certain shooting conditions.
- Raising the ISO speed results in a faster shutter speed, reducing image blurring and letting the flash reach greater distances to the subject. The images, however, will appear coarse.

When the camera is set to ISO AUTO, you can press the shutter button halfway to display the automatically set ISO speed.

Downloaded From camera-usermanual.com Canon Manuals

Adjusting the White Balance

The white balance (WB) function sets the optimal white balance for natural looking colors to match the shooting conditions.

1 Choose the white balance function.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose AWB, then press the (FUNC SET) button again.

2 Choose an option.

- Press the ▲▼ buttons or turn the dial to choose an option, then press the (FUNC SET) button.
- ▶ The setting will appear on the screen.

AWB	Auto	Automatically sets the optimal white balance for the shooting conditions.
☀	Day Light	Fine weather conditions, outdoor shooting
☁	Cloudy	Cloudy, shady, twilight conditions
💡	Tungsten	Tungsten, bulb-type (3-wavelength) fluorescent lighting
	Fluorescent	Warm-white fluorescent, cool-white fluorescent, warm-white-type (3-wavelength) fluorescent lighting
H	Fluorescent H	Daylight fluorescent, daylight-type (3-wavelength) fluorescent lighting
	Custom	Manually sets a custom white balance.

Custom White Balance

You can adjust the white balance to the light source at the shooting location. Make sure that you set the white balance under the light source of the actual scene you will shoot.



- In Step 2 above, choose .
- Make sure the entire screen is filled with a plain, white colored subject, then press the MENU button.
- ▶ The tint on the screen will change when a white balance data is set.

If you change camera settings after recording white balance data, the tone may not turn out properly.

Downloaded From camera-usermanual.com Canon Manuals

Continuous Shooting

As long as you hold the shutter button down, the camera will shoot continuously.

1 Choose a Drive mode.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose □, then press the (FUNC SET) button again.

2 Choose an option.

- Press the ▲▼ buttons or turn the dial to choose Continuous or AF Continuous, then press the (FUNC SET) button.

3 Shoot.

- As long as you hold the shutter button down, the camera will shoot successive images.

Mode	Maximum Speed (Approx. images/sec.)	Description
Continuous	3.7	The camera shoots continuously with the focus and exposure set when the shutter button is pressed halfway.
AF Continuous Shooting AF	0.8	The camera shoots continuously and focuses. The [AF Frame] is set to [Center].
LV Continuous Shooting LV*	0.9	In mode, the focus is locked on the first shot.

* When in (p. 63) or AF lock modes (p. 86), AF will change to LV.

- Cannot be used with the self-timer (pp. 60, 80, 81).
- Continuous shooting speed increases in mode (p. 62).
- Depending on the shooting conditions, the camera settings and the zoom position, the camera may stop shooting momentarily, or the shooting speed may slow down.
- As the number of images increases, the shooting speed may slow down.
- If the flash fires, the shooting speed may slow down.

Downloaded From camera-usermanual.com Canon Manuals

Changing the Tone of an Image (My Colors)

You can change the tone of an image to sepia or black and white when shooting.

1 Choose My Colors.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose OFF, then press the (FUNC SET) button again.

2 Choose an option.

- Press the ▲▼ buttons or turn the dial to choose an option, then press the (FUNC SET) button.
- ▶ The setting will appear on the screen.

OFF	My Colors Off	—
V	Vivid	Emphasizes the contrast and color saturation for a vivid impression.
N	Neutral	Tones down the contrast and color saturation for neutral hues.
Se	Sepia	Sepia tones.
BW	B/W	Black and white.
P	Positive Film	Combines the effects of Vivid Red, Vivid Green and Vivid Blue to produce intense natural appearing colors like those obtained with positive film.
L	Lighter Skin Tone	Makes skin tones lighter.
D	Darker Skin Tone	Makes skin tones darker.
B	Vivid Blue	Emphasizes blue tints. Makes the sky, ocean and other blue subjects more vivid.
G	Vivid Green	Emphasizes green tints. Makes mountains, foliage and other green subjects more vivid.
R	Vivid Red	Emphasizes red tints. Makes red subjects more vivid.
C	Custom Color	You can adjust contrast, sharpness, and color saturation etc. to your preference (p. 80).

- The white balance cannot be set in the Se and BW modes (p. 77).
- In L and D modes, colors other than people's skin color may change. You may not obtain the expected results with some skin colors.

Downloaded From camera-usermanual.com Canon Manuals

Custom Color

The contrast, sharpness, color saturation, red, green, blue, and skin tones in an image can be chosen and set at 5 different levels.

- Follow Step 2 on p. 79 to choose Custom Color, then press the MENU button.
- Press the ▲▼ buttons to choose an option, then press the ◀▶ buttons or turn the dial to choose a value.
- The more to the right, the stronger/darker (skin tone) the effect gets, the more to the left, the weaker/lighter (skin tone) the effect gets.
- Press the MENU button to complete the setting.

Using the Self-Timer to Prevent Camera Shake

The camera will shoot approximately two seconds after the shutter button is pressed, preventing any camera shake that occurs when pressing the shutter button.

Choose ⏲2.

- After pressing the ▲ button, press the ▲▼ buttons or turn the dial to choose ⏲2, then press the FUNC SET button.
- ▶ Once set, ⏲2 will appear on the screen.
- Follow Step 3 on p. 60 to shoot.

Downloaded From camera-usermanual.com Canon Manuals

Customizing the Self-Timer

You can set the time delay (0 – 30 seconds) and the number of shots (1 – 10 shots).



1 Choose ⏲.

- After pressing the ▲ button, press the ▲▼ buttons or turn the dial to choose ⏲, then press the MENU button immediately.



2 Choose the settings.

- Press the ▲▼ buttons to choose [Delay] or [Shots].
- Press the ◀▶ buttons or turn the dial to choose a value, then press the (FUNC SET) button.
- Follow Step 3 on p. 60 to shoot.

What if the number of shots is set to two or more shots?

- Exposure and white balance settings are set with the first shot.
- If the flash fires or you set a high number of shots, the shooting interval may take longer than usual.
- If the memory card becomes full, shooting stops automatically.

When you set the time delay for more than 2 seconds, the self-timer lamp and sound speed up 2 seconds before the shutter releases (when the flash will fire, the lamp lights).

Downloaded From camera-usermanual.com Canon Manuals

Shooting Using a TV Monitor

You can use a TV to display the camera screen content while shooting.

- To connect the camera to a TV, follow the Steps in “Viewing Images on a TV” (p. 115).
- Shooting procedures are the same as when using the camera screen.

TV display is not available when using HDMI Cable HTC-100 (sold separately) to connect the camera to a high-definition TV.

Changing the Composition with the Focus Lock

While you keep the shutter button pressed halfway, the focus and exposure are locked. You can now recompose and shoot. This is called Focus Lock.

1 Focus.

- Center the subject you want in focus, and press the shutter button halfway.
- Confirm that the AF Frame on the subject is green.

2 Recompose.

- Keep the shutter button pressed halfway and move the camera to recompose the scene.

3 Shoot.

- Press the shutter button fully.

Downloaded From camera-usermanual.com Canon Manuals

5

Getting More Out of Your Camera

This chapter serves as the advanced version of Chapter 4 and explains how to take pictures using various functions.

- This chapter assumes that you have set the mode switch to 📷 and set the camera to **P** mode.
- The sections “Changing the Color and Shooting” (p. 92), “Shooting Long Exposures” (p. 95) and “Shooting Stitch Assist Images” (p. 96) assume you have set the mode switch to 📷 and chosen the corresponding mode.
- Before attempting to shoot using a function explained in this chapter in modes other than **P** mode, check if the function is available in those modes (pp. 166 – 169).

Downloaded From camera-usermanual.com Canon Manuals

Changing the AF Frame Mode

You can change the AF (Auto Focus) frame mode to match the scene you want to shoot.



Choose [AF Frame].

- After pressing the MENU button, choose [AF Frame] in the tab, then press the ◀▶ buttons to choose an option.

Face Detect

- Detects people's faces and sets the focus, exposure (evaluative metering only) and white balance (AWB only).
- When the camera is pointed at subjects, a white frame appears on the face the camera judges to be the main subject, and gray frames (max. 2) will appear on other faces.
- A frame will follow a moving subject within a certain range.
- When the shutter button is pressed halfway, up to 9 green frames will appear on faces that the camera focuses on.

- If a face is not detected and only gray frames (no white frame) appear, an AF Frame will appear in the center of the screen when you press the shutter button halfway.
- The AF frame will appear in the center of the screen if you press the shutter button halfway when Servo AF (p. 86) is set to [On] and a face is not detected.
- Examples of faces that cannot be detected:
  - Subjects that are far away or extremely close.
  - Subjects that are dark or light.
  - Faces turned to the side or at a diagonal, or faces with a portion hidden.
- The camera may mistakenly identify non-human subjects as a face.
- If the camera cannot focus when you press the shutter button halfway, the AF frame will not appear.

Center

The AF frame is locked to the center. This is effective for focusing on a specific point.

Downloaded From camera-usermanual.com Canon Manuals

You can reduce the AF frame size

- Press the MENU button to choose [AF Frame Size] in the tab, then choose [Small].
- The AF frame is set to [Normal] when using Digital Zoom (p. 57) or Digital Tele-converter (p. 58).

If the camera cannot focus when you press the shutter button halfway, the AF frame will turn yellow and ! will appear.

Magnifying the Focal Point

If you press the shutter button halfway, the AF frame will magnify and you can check the focus.



1 Choose [AF-Point Zoom].

- Press the MENU button to choose [AF-Point Zoom] in the tab, then press the ◀▶ buttons to choose [On].

2 Check the focus.

- Press the shutter button halfway.
- ▶ In [Face Detect] (p. 84), the face detected as the main subject will appear magnified.
- ▶ In [Center] (p. 84), the contents of the center AF frame will appear magnified.

What if the display does not magnify?

The display will not appear magnified in [Face Detect] if a face cannot be detected or is too big in relation to the screen. In [Center], it will not appear magnified if the camera cannot focus.

The magnified display will not appear when using Digital Zoom (p. 57), Digital Tele-converter (p. 58), Servo AF (p. 86) or when connected to a TV (p. 82).

Downloaded From camera-usermanual.com Canon Manuals

Shooting with the AF Lock

The focus can be locked. After locking the focus, the focal distance will not change even when you release your finger from the shutter button.



1 Lock the focus.

- Keep the shutter button pressed halfway and press the ◀ button.
- ▶ The focus locks and AFL appears on the screen.
- If you release your finger from the shutter button and press the ◀ button again, AFL will disappear and the focus will unlock.

2 Compose the scene and shoot.

Shooting with Servo AF

While the shutter button is pressed halfway, the focus and exposure will continue to adjust, allowing you to take pictures of moving subjects without missing a shot.

1 Choose [Servo AF].

- Press the MENU button to choose [Servo AF] in the 📷 tab, then press the ◀▶ buttons to choose [On].

2 Focus.

- The focus and exposure will be maintained where the blue AF frame appears while you press the shutter button halfway.

Downloaded From camera-usermanual.com Canon Manuals

- The camera may not be able to focus in some conditions.
- In low light conditions, AF frames may not turn blue even after pressing the shutter button halfway. In this case, you can set the focus and exposure with the AF frame setting.
- If a correct exposure cannot be obtained, the shutter speed and aperture value appear in orange. Release your finger from the shutter button, then press it again halfway.
- You cannot shoot with the AF lock in this mode.
- The [AF-Point Zoom] option in the 📷 tab is not available in Servo AF mode.
- Not available when using Self-Timer (pp. 60 , 80, 81).

Changing the Metering Method

You can change the metering method (brightness measuring function) to match the shooting conditions.

1 Choose the metering method.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose [⊙], then press the (FUNC SET) button again.

2 Choose an option.

- Press the ▲▼ buttons or turn the dial to choose an option, then press the (FUNC SET) button.

▶ The setting will appear on the screen.

[⊙] Evaluative	Suitable for standard shooting conditions, including back lit shots. Automatically adjusts the exposure to match the shooting conditions.
[ ] Center Weighted Avg.	Averages the light metered from the entire frame, but gives greater weight to the center.
[•] Spot	Only meters within the [ ] (Spot AE Point frame) that appears at the center of the screen.

Downloaded From camera-usermanual.com Canon Manuals

Shooting with the AE Lock

You can lock the exposure and shoot, or set the focus and exposure separately to shoot. AE stands for “Auto Exposure”.



1 **Choose ⚡ (p. 56).**

2 **Lock the exposure.**

- Point the camera toward the subject and press the ▲ button while pressing the shutter button halfway.
- ▶ When AEL appears, the exposure will be locked.
- If you release your finger from the shutter button and press the ▲ button again, AEL will disappear and AE will unlock.

3 **Compose the scene and shoot.**

Shooting with the FE Lock

Just as with the AE lock (p. 88), you can lock the exposure for shooting with the flash. FE stands for “Flash Exposure”.



1 **Choose ϟ (p. 73).**

2 **Lock the flash exposure.**

- Point the camera toward the subject and press the ▲ button while pressing the shutter button halfway.
- ▶ The flash will fire and when FEL appears, the flash output will be retained.
- If you release your finger from the shutter button and press the ▲ button again, FEL will disappear and FE will unlock.

3 **Compose the scene and shoot.**

Downloaded From camera-usermanual.com Canon Manuals

Shooting with Slow Synchro

You can make the main subject, such as people, appear bright by having the camera provide the appropriate illumination with the flash. At the same time, you can use a slow shutter speed to brighten the background that the light from the flash cannot reach.



1 Choose .

- After pressing the ▶ button, press the ◀▶ buttons or turn the dial to choose , then press the (FUNC SET) button.
- ▶ Once set, will appear on the screen.

2 Shoot.

- Even if the flash fires, ensure that the subject does not move until the shutter sound ends.

Attach the camera to a tripod to prevent the camera from moving and blurring the image. Additionally, you should set the [IS Mode] to [Off] when shooting with a tripod (p. 150).

Downloaded From camera-usermanual.com Canon Manuals

Correcting the Brightness and Shooting (i-Contrast)

The camera can detect areas in the scene, such as faces or backgrounds, that are too bright or dark and automatically adjust them to the optimum brightness when shooting. Also, when the overall image is lacking in contrast, the camera will automatically correct the image for a sharper impression when shooting.



Choose [i-Contrast].

- Press the MENU button and choose [i-Contrast] in the tab, then press the ◀▶ buttons to choose [Auto].
- Once set, will appear on the screen.

Under some conditions, the image may appear coarse or may not be corrected properly.

You can correct recorded images (p. 130).

Red-Eye Correction

You can automatically correct red-eye that occurs in images taken with the flash.



1 Choose [Flash Settings].

- Press the MENU button to choose [Flash Settings] in the tab, then press the FUNC SET button.



2 Adjust the setting.

- Press the ▲▼ buttons or turn the dial to choose [Red-Eye Corr.], then press the ◀▶ buttons to choose [On].
- Once set, will appear on the screen.

Downloaded From camera-usermanual.com Canon Manuals

Red-eye correction may be applied to areas other than red eyes.
For example, when red make-up has been used around eyes.

- You can correct recorded images (p. 130).
- You can also display the screen in Step 2 by pressing the ▶ button, then the MENU button.

Checking for Shut Eyes

When the camera detects the possibility that people have their eyes shut, appears.

1 Choose [Blink Detection].

- Press the MENU button, then choose [Blink Detection] in the tab. Press the ◀▶ buttons to choose [On].

2 Shoot.

- When a person with shut eyes is detected, a frame and appear.

- In or mode, when the number of shots is set to two or more, this function is only available for the last image shot.
- Not available in , , or mode.

Downloaded From camera-usermanual.com Canon Manuals

Changing the Color and Shooting

You can change the look of an image when shooting. However, depending on shooting conditions the image may become coarse, or the colors may not come out as expected.

Color Accent

You can choose to retain a single color and change the rest to black and white in a composition.

1 Choose A.

- Follow Steps 1 – 2 on p. 61 to choose A.

2 Press the MENU button for more than one second.

- The unchanged image and the Color Accent image will alternately display.
- The color for default settings is green.

Recorded color

3 Specify the color.

- Position the center frame so it is filled with the color you want and press the ◀ button.
- The specified color will be recorded.

4 Specify the range of colors.

- Press the ▲▼ buttons or turn the dial to change the range of colors to be retained.
- Choose a negative value to limit the range of colors. Choose a positive value to extend the range of colors to similar colors.
- Pressing the MENU button accepts the setting and restores the shooting screen.

Using the flash may cause unexpected results in this mode.

Downloaded From camera-usermanual.com Canon Manuals

Color Swap

You can swap one color in an image for another when recording it. You can only swap one color.

1 Choose ✎S.

- Follow Steps 1 – 2 on p. 61 to choose ✎S.

2 Press the MENU button for more than one second.

- ▶ The unchanged image and the Color Swap image will alternately display.
- The default setting is to change green to gray.

3 Specify the color to be swapped.

- Position the center frame so it is filled with the color you want and press the ◀ button.
- ▶ The specified color will be recorded.

4 Specify the target color.

- Position the center frame so it is filled with the color you want and press the ▶ button.
- ▶ The specified color will be recorded.

Downloaded From camera-usermanual.com Canon Manuals

5 Specify the range of colors to be swapped.

- Press the ▲▼ buttons or turn the dial to adjust the range of colors to be changed.
- Choose a negative value to limit the range of colors. Choose a positive value to extend the range of colors to similar colors.
- Pressing the MENU button accepts the setting and restores the shooting screen.

- Using the flash may cause unexpected results in this mode.
- Under some conditions, the image may appear coarse.

Downloaded From camera-usermanual.com Canon Manuals

Shooting Long Exposures

You can set the shutter speed to a range between 1 and 15 seconds to shoot long exposures. However, you should attach the camera to a tripod to prevent the camera from moving and blurring the image.



1 Choose ★.

- Choose ★ in Steps 1 – 2 on p. 61.



2 Choose the shutter speed.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose 1", then press the (FUNC SET) button again.
- Press the ▲▼ buttons or turn the dial to choose the shutter speed, then press the (FUNC SET) button.

3 Confirm the exposure.

- When you press the shutter button halfway, the exposure for the chosen shutter speed will appear on the screen.

- The brightness of the image may differ from the brightness of the screen in Step 3 when the shutter button was pressed halfway.
- When shutter speeds of 1.3 seconds or slower are used, images are processed to eliminate noise after being taken. A certain amount of processing time may be needed before you can take the next shot.
- You should set the [IS Mode] to [Off] when shooting with a tripod (p. 150).

If the flash fires, the image may be overexposed. If this happens, set the flash to ⚡ and shoot.

Downloaded From camera-usermanual.com Canon Manuals

Shooting Stitch Assist Images

Large subjects can be split into several shots that can later be merged together using the included software on a computer to create a panoramic image.

1 Choose or .

- Follow Steps 1 – 2 on p. 61 to choose or .

2 Take the first shot.

- The exposure and white balance will be set with the first shot.

3 Take subsequent shots.

- Overlap part of the first shot when taking the second shot.
- Minor discrepancies in the overlapping portions will be corrected when the images are merged.
- Up to 26 shots can be recorded with the same procedures.

4 Finish shooting.

- Press the (FUNC SET) button.

5 Merge the images on a computer.

- For details on how to merge the images, refer to the *Software Guide*.

This function is not available when a TV is used as the monitor (p. 82).

Downloaded From camera-usermanual.com Canon Manuals

6

Using Various Functions for Shooting Movies

This chapter serves as a more advanced version of the “Shooting Movies” and “Viewing Movies” sections in Chapter 1, and explains how to use various functions for shooting and viewing movies.



- This chapter assumes that the mode switch is set to 🎥.
- The latter half of the chapter explaining movie playback and editing assumes that the ▶ button has been pressed to enter Playback mode.

Shooting Movies in Modes Other than 🎥

- When the mode switch is set to AUTO, the camera can automatically select all settings so that you can shoot movies (p. 30).
- You can shoot movies by pressing the movie button, however, certain settings made in the FUNC. and Shooting menus will automatically change to match settings for shooting movies.
- When you finish shooting a movie, the settings will return to those before the movie was shot.

Downloaded From camera-usermanual.com Canon Manuals

Shooting Movies in Mode



1 Enter mode.

- Set the mode switch to .

2 Adjust the settings according to your purposes (pp. 98 – 103).

3 Shoot.

- Press the movie button.
- To stop shooting the movie, press the movie button again.

Changing the Movie Mode

You can choose between five Movie modes.

Choose a Movie mode.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose , then press the (FUNC SET) button again.
- Press the ▲▼ buttons or turn the dial to choose a mode, then press the (FUNC SET) button.

Standard	Normal mode.
Super Slow Motion	Captures fleeting moments at high-speed for playback in slow motion (p. 99).
Miniature Effect	You can shoot movies that look like a miniature model (p. 99).
Color Accent	These Shooting modes let you change all colors except the chosen color to black and white, or exchange the chosen color for another color, when shooting. See “Changing the Color and Shooting” (p. 92) for details. Choose the color you wish to leave in or change before shooting the movie.
Color Swap	

Under some conditions, colors may not turn out as expected in and modes.

- Pressing the movie button in mode will record a movie in .
- Even if you press the movie button when in or , you can shoot movies with Color Accent (p. 92) or Color Swap (p. 93).

Downloaded From camera-usermanual.com Canon Manuals

Shooting Super Slow Motion Movies

You can shoot fast moving subjects and play them back in slow motion. The maximum clip length you can record is approximately 30 seconds long, which will take approximately 4 minutes to play back in slow motion.

1 Choose .

- Follow the steps for "Changing the Movie Mode" on p. 98 to choose .

2 Shoot.

- Press the movie button.
- To stop shooting the movie, press the movie button again.

Viewing Super Slow Motion Movies

- The movie will play back in slow motion when you following Steps 1 – 3 on p. 32.
- You can use the included software to change the playback speed of movies shot in . Refer to the *Software Guide* for details.

- Even if you press the zoom lever, the zoom will not operate while shooting.
- The focus, exposure and white balance will be set when the movie button is pressed.

Shoot Movies That Look Like a Miniature Model (Miniature Effect)

You can shoot movies that look like moving miniature models.
You create the miniature model effecty by choosing the upper and lower portions of the scene that will be blurred and the playback speed, which makes people and objects in the scene move quickly during playback.
Audio will not be recorded.

1 Choose .

- Follow the steps for "Changing the Movie Mode" on p. 98 to choose .

Downloaded From camera-usermanual.com Canon Manuals

▶ A white frame (the area that will not be blurred) appears on the screen.

2 Choose the area to keep in focus.

- Press the MENU button for more than one second.
- Move the zoom lever to change the frame size, and press the ▲▼ buttons to change the frame position.

3 Choose a playback speed.

- Press the FUNC. SET button.
- Press the ◀▶ buttons or turn the dial to choose a playback speed.
- Pressing the MENU button restores the settings screen.

4 Shoot.

- Press the movie button.
- To stop shooting the movie, press the movie button again.

Playback Speeds and Estimated Playback Times (for 1 Min. Clips)

Speed	Playback Time
5x	12 sec.
10x	6 sec.
20x	3 sec.

- For the screen in Step 2, pressing the ◀▶ buttons will allow you to change the frame vertical orientation and also change the area to focus in. Pressing the ▲▼ buttons will return the frame to horizontal orientation.
- Holding the camera vertically will change the orientation of the frame.
- Since you may not achieve the expected results depending on the shooting conditions, try taking some test shots first.

Downloaded From camera-usermanual.com Canon Manuals

Changing the Movie Quality

You can choose between four movie quality settings.

1 Choose the movie quality setting.

- After pressing the (FUNC. SET) button, press the ▲▼ buttons or turn the dial to choose 1920, then press the (FUNC. SET) button again.

2 Choose an option.

- Press the ▲▼ buttons or turn the dial to choose an option, then press the (FUNC. SET) button.

▶ The option you set will appear on the screen.

Movie Quality Table

Movie Quality (Recording Pixels/Frame Rate)	Content
1920 1920 x 1080 pixels, 24 frames/sec.	For shooting full high-definition movies.
1280 1280 x 720 pixels, 30 frames/sec.	For shooting high-definition movies.
640 640 x 480 pixels, 30 frames/sec.	For shooting standard quality movies.
320 320 x 240 pixels, 30 frames/sec.	Since the number of recording pixels is smaller than in 640, the movie quality will appear coarse, but you can record approximately three times the length.

Estimated Shooting Time

Movie Quality	Shooting Time	
	4 GB	16 GB
1920	14 min. 34 sec.	59 min. 40 sec.
1280	20 min. 43 sec.	1 hr. 24 min. 54 sec.
640	43 min. 43 sec.	2 hrs. 59 min. 3 sec.
320	1 hr. 58 min. 19 sec.	8 hrs. 4 min. 30 sec.

- Based on Canon's testing standards.
- Recording will automatically stop when the clip file size reaches 4 GB, or when the recording time reaches approximately 10 minutes when shooting in 1920 or 1280, and approximately 1 hour when shooting in 640 or 320.
- Recording may stop even if the maximum clip length has not been reached on some memory cards. SD Speed Class 6 or higher memory cards are recommended.

Downloaded From camera-usermanual.com Canon Manuals

AE Lock/Exposure Shift

You can lock the exposure or change it in 1/3 steps within a range of ±2 before shooting.

1 Focus.

- Press the shutter button halfway to focus.

2 Lock the exposure.

- After releasing the shutter button, press the ▶ button to lock the exposure. The exposure shift bar appears.
- Press the ▶ button again to release the lock.

3 Change the exposure.

- While watching the screen, turn the dial to adjust the exposure.

4 Shoot.

- Press the movie button.
- To stop shooting the movie, press the movie button again.

Downloaded From camera-usermanual.com Canon Manuals

Other Shooting Functions

The following functions can be used in the same way as for still images. Functions marked with a * can be used in the same way as for still images when in , , or .

- **Zooming in More Closely On Subjects**
  - The optical and digital zooms (p. 57) are available in .
  - Only the optical zoom is available in and .
  - Neither the optical nor digital zooms are available while shooting in . Be sure to set the optical zoom before shooting.
  - The sound of the zoom will be recorded.
- **Using the Self-Timer (p. 60)***
- **Changing the Focusing Range (Macro/Infinity) (p. 73)**
  Neither macro nor infinity shooting are available in .
- **Adjusting the White Balance (p. 77)**
- **Changing the Tone of an Image (My Colors) (p. 79)**
- **Using the Self-Timer to Prevent Camera Shake (p. 80)***
- **Customizing the Self-Timer (p. 81)**
  The number of shots cannot be changed.
- **Shooting Using a TV Monitor (p. 82)***
- **Shooting with the AF Lock (p. 86)**
- **Turning Off the AF Assist Beam (p. 147)***
- **Displaying the Overlay (p. 149)***
  [3:2 Guide] is not available.
- **Changing the IS-Mode Settings (p. 150)***
  You can switch between [Continuous] and [Off].

Downloaded From camera-usermanual.com Canon Manuals

Playback Functions

The following functions can be used in the same way as for still images.

- **Erasing Images** (p. 29)
- **Quickly Searching Images** (p. 108)
- **Viewing Images in Filtered Playback** (p. 109)
- **Viewing Slideshows** (p. 110)
- **Changing Image Transitions** (p. 114)
- **Viewing Images on a TV** (p. 115)
- **Viewing Images on a High-Definition TV** (p. 116)
- **Protecting Images** (p. 117)
- **Erasing Images** (p. 120)
- **Tagging Images as Favorites** (p. 122)
- **Organizing Images by Category (My Category)** (p. 123)
- **Rotating Images** (p. 126)

Summary of Movie Control Panel in "Viewing Movies" (p. 32)

⮌	Exit
▶	Playback
▶	Slow motion playback (you can use the ◀▶ buttons or the ◎ dial to adjust the speed. Sound will not play back.)
⏮	Display the first frame
◀	Previous frame (Rewind if you hold down the FUNC SET button.)
▶	Next frame (Fast forward if you hold down the FUNC SET button.)
⏭	Display the last frame
✂	Edit (p. 105)
🖨	Appears when connected to a PictBridge compliant printer (p. 134). Refer to the *Personal Printing Guide* for details.

Downloaded From camera-usermanual.com Canon Manuals

Editing

You can trim the beginnings and ends of recorded movies.

Movie Editing Panel

Movie Editing Bar

1 Choose ✂.

- Follow Steps 1 – 3 on p. 32 to choose ✂, then press the (FUNC SET) button.
- ▶ The movie editing panel and the movie editing bar will appear.

2 Set the editing range.

- Press the ▲▼ buttons and choose ✂ or ✂.
- Press the ◀▶ buttons or turn the dial to move ▮. ✂ will display at a point where you can edit the movie. If you choose ✂, you can trim the beginning of the movie from ✂. If you choose ✂, you can trim the end of the movie from ✂.
- ▶ Even if you move ▮ to a point other than a ✂, only the portion from the nearest ✂ to the left will be trimmed when ✂ is chosen. Only the portion from the nearest ✂ to the right will be trimmed when ✂ is chosen.
- ▶ The section indicated with ▮ will be the section of the movie that remains after editing.

Downloaded From camera-usermanual.com Canon Manuals

3 Check the edited movie.

- Press the ▲▼ buttons to choose ▶ (Play), then press the (FUNC SET) button. The edited movie will play.
- To edit the movie again, repeat Step 2.
- To cancel editing, press the ▲▼ buttons, and choose ↩. After pressing the (FUNC SET) button, press the ◀▶ buttons or turn the dial to choose [OK], then press the (FUNC SET) button again.



4 Save the edited movie.

- Press the ▲▼ buttons to choose , then press the (FUNC SET) button.
- Press the ▲▼◀▶ buttons, or turn the dial to choose [New File], then press the (FUNC SET) button.

▶ The movie will be saved as a new file.

- When [Overwrite] is chosen in Step 4, the unedited movie is overwritten with the edited movie, erasing the original.
- When there is not enough space left on the memory card, only [Overwrite] can be chosen.
- If the battery is depleted partway through editing, the edited movie clips may not be saved.
- When editing movies, you should use a fully charged battery, or an AC adapter kit (sold separately) (p. 39).

Downloaded From camera-usermanual.com Canon Manuals

7

Using Various Playback and Editing Functions

This chapter explains various ways to play back and edit images.

- Press the ▶ button to enter Playback mode before operating the camera.

- It may not be possible to play back or edit images that have been edited on a computer, had their file name changed, or have been taken on a different camera.
- The edit function (pp. 127 – 131) cannot be used if the memory card does not have free space available.

Downloaded From camera-usermanual.com Canon Manuals

Quickly Searching Images

Searching Images Using Index Display

Displaying multiple images at the same time lets you quickly find the image you want.



1 Move the zoom lever toward ▪.

- ▶ Images will display in an index.
- The number of images increases each time you move the lever toward ▪.
- The number of images decreases each time you move the lever toward 🔍.

2 Choose an image.

- Turn the ◎ dial to switch images.
- Press the ▲▼◀▶ buttons to choose an image.
- ▶ An orange frame appears on the chosen image.
- Press the (FUNC SET) button to display the chosen image by itself.

Searching Images Using the Control Dial

Turning the control dial will display images in a line letting you quickly search them. You can also jump by the shooting date (Scroll Display).

Choose an image.

- If you set the camera to single image playback and turn the ◎ dial quickly, the images will display as shown on the left. Turn the ◎ dial to choose an image.
- Pressing the (FUNC SET) button restores single image playback.
- If you press the ▲▼ buttons during Scroll Display, you can search images by the shooting date.

To turn off this effect, press the MENU button to choose [Scroll Display] in the ▶ tab, then choose [Off].

Downloaded From camera-usermanual.com Canon Manuals

Viewing Images in Filtered Playback

When there are many images on the memory card, you can filter and display them by a specified filter. You can also protect (p. 117) or delete (p. 120) all images at once while filtered.



1 Choose .

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose , then press the (FUNC SET) button again.

2 Choose a filter.

- Press the ▲▼ buttons or turn the dial to choose a filter, then press the (FUNC SET) button.

3 View the filtered images.

- Press the ▲▼ buttons or turn the dial to choose a filter for playback, then press the (FUNC SET) button (except for ★).
- ▶ Filtered playback starts and a yellow frame appears.
- If you press the ◀▶ buttons or turn the dial, only the chosen target images will display.
- If you choose in Step 2, filtered playback will be canceled.

Search filters

★	Favorites	Displays images tagged as favorites (p. 122)
	Shot Date	Displays the images shot on a specified date
	My Category	Displays the images of a specified category (p. 123)
	File Type	Displays only still images or movies

What if you can't choose a filter?

Filters that do not have any corresponding images cannot be chosen.

Downloaded From camera-usermanual.com Canon Manuals

Filtered playback

In filtered playback (Step 3), you can view filtered images with “Quickly Searching Images” (p. 108), “Viewing Slideshows” (p. 110), and “Magnifying Images” (p. 113). You can process all filtered images at once while performing operations in “Protecting Images” (p. 117), “Erasing Images” (p. 120), or “Printing from the Print List (DPOF)” (p. 137), by choosing all of the filtered images.
However, if you change the category (p. 123), or edit an image and save it as a new image (p. 127), a message will appear, and filtered playback will cancel.

Viewing Slideshows

You can automatically play back images recorded to a memory card. Each image displays for approximately 3 seconds.

1 Choose .

- After pressing the FUNC SET button, press the ▲▼ buttons or turn the dial to choose , then press the FUNC SET button again.

2 Choose a transition effect.

- Press the ▲▼ buttons or turn the dial to choose an effect, then press the FUNC SET button.



- The slideshow will start a few seconds after [Loading image...] appears.
- In filtered playback (p. 109), only images matching a filter play back.
- You can pause/restart a slideshow by pressing the FUNC SET button again.
- Press the MENU button to stop the slideshow.

- If you press the ◀▶ buttons or turn the dial during playback, the image will switch. If you keep the ◀▶ buttons pressed, you can fast-forward through images.
- The power saving function (p. 51) does not work during slideshows.

Downloaded From camera-usermanual.com Canon Manuals

Changing Settings

You can set a slideshow to repeat, or change transition effects and the time that slideshow images are displayed. You can choose from six transition effects when switching between images.

1 Choose [Slideshow].

- Press the MENU button to choose [Slideshow] from the ▶ tab, then press the (FUNC SET) button.



2 Make the setting.

- Press the ▲▼ buttons or turn the dial to choose an item, then press the ◀▶ buttons to adjust the setting.
- If you choose [Start] and press the (FUNC SET) button, the slideshow starts with your settings.
- Pressing the MENU button will restore the menu screen.

You cannot change [Play Time] if [Bubble] is chosen in [Effect].

Downloaded From camera-usermanual.com Canon Manuals

Checking the Focus

You can magnify the area of a recorded image that was inside the AF Frame, or the area of a face that was detected, to check the focus.

1 Press the ▼ button to switch to the focus check display (p. 44).

- A white frame will appear where the AF frame or face was when the focus was set.
- A gray frame will appear on a face detected during playback.
- The area within the orange frame appears magnified.

2 Switch frames.

- Move the zoom lever toward Q once.
- The screen shown to the left will appear.
- Press the (FUNC SET) button to move to a different frame when multiple frames appear.

3 Change the magnification level or location.

- Use the zoom lever to change the display size, and the ▲▼◀▶ buttons to change the display position while checking the focus.
- Pressing the MENU button resets the display to Step 1.

Downloaded From camera-usermanual.com Canon Manuals

Magnifying Images



Approximate Location of Displayed Area

Move the zoom lever toward Q.

- The display will zoom in on the image. If you continue to hold the zoom lever, it will zoom in up to a maximum factor of 10x.
- If you press the ▲▼◀▶ buttons, you can move the location of the displayed area.
- Move the zoom lever toward ▪ to zoom out, or continue to hold it to return to single image playback.
- If you turn the ◎ dial, you can switch images while zoomed.

You can return to single image playback immediately by pressing the MENU button while the image is magnified.

Displaying Various Images (Smart Shuffle)

The camera will choose four images based on the displayed image.
If you choose one of those images, the camera will choose four more images letting you enjoy the playing back of images in an unexpected order.
This will work best if you take many shots of various scenes.

1 Choose 🎲.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the ◎ dial to choose 🎲, then press the (FUNC SET) button again.
- ▶ Four images will appear as possibilities.

Downloaded From camera-usermanual.com Canon Manuals

2 Choose an image.

- Press the ▲▼◀▶ buttons to choose the image you want to view next.
- The chosen image will be displayed in the middle, and the next four possibilities will appear.
- Pressing the (FUNC SET) button will display the middle image at full size. Press the (FUNC SET) button again to restore the original display. You can also use the zoom lever in the same way.
- Pressing the MENU button restores single image playback.

- Only still images shot with this camera will play back in Smart Shuffle.
- is not available in the following situations:
  - If there are less than 50 images taken with this camera on the memory card.
  - If you play back images not supported by Smart Shuffle.
  - During filtered playback.

Changing Image Transitions

You can choose from three transition effects when switching between images in single image playback.

Choose [Transition].

- Press the MENU button to choose [Transition] in the ▶ tab, then press the ◀▶ buttons to choose a transition effect.

Downloaded From camera-usermanual.com Canon Manuals

Viewing Images on a TV

Using the supplied stereo AV cable (p. 2), you can connect the camera to a TV to view images you have shot.

1 Turn off the camera and TV.



2 Connect the camera to the TV.

- Open the camera's terminal cover and fully insert the cable plug into the camera's terminal.



- Insert the cable plug fully into the video input terminals as shown in the illustration.

3 Turn on the TV and switch it to the input the cable is connected to.

4 Turn on the camera.

- Press the ▶ button to turn on the camera.
- ▶ The image will appear on the TV (nothing will appear on the screen of the camera).
- After you finish, turn off the camera and TV, and unplug the cable.

What if the images don't display correctly on the TV?

Images will not display correctly if the camera's video output setting (NTSC/PAL) does not match the TV system. Press the MENU button, choose the tab and [Video System] to switch to the correct video system.

Downloaded From camera-usermanual.com Canon Manuals

Viewing Images on a High-Definition TV

Use the separately sold HDMI Cable HTC-100 to connect the camera to a high-definition TV for an enhanced viewing experience.

1 Turn off the camera and TV.



2 Connect the camera to the TV.

- Open the camera's terminal cover and fully insert the cable plug into the camera's terminal.



- Fully insert the cable plug into the TV's HDMI terminal.

3 Display images.

- Follow Steps 3 and 4 on p. 115 to display the images.

The supplied stereo A/V and interface cables and the separately sold HDMI Cable HTC-100 cannot be plugged into the camera at the same time. Doing so could cause the camera to malfunction.

Operation sounds will not play when connected to a high-definition TV.

Downloaded From camera-usermanual.com Canon Manuals

Protecting Images

You can protect important images so that they cannot be accidentally erased with the camera (pp. 29, 120).

Protect the image.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose 🔑, then press the (FUNC SET) button again.
- [Protected] will appear on the screen.
- To unlock an image, follow the Step above to choose 🔑 again, then press the (FUNC SET) button.

If you format the memory card (pp. 23, 52), protected images will also be erased.

Protected images cannot be erased with the camera's erase function. To erase an image, cancel protection settings first.

Using the Menu

1 Choose [Protect].

- Press the MENU button to choose [Protect] in the ▶ tab, then press the (FUNC SET) button.



2 Choose a selection method.

- Press the ▲▼ buttons or turn the dial to choose a selection method, then press the (FUNC SET) button.
- Pressing the MENU button will restore the menu screen.

Choosing Images Individually

1 Choose [Select].

- Follow Step 2 above to choose [Select], then press the (FUNC SET) button.

Downloaded From camera-usermanual.com Canon Manuals

2 Choose images.

- Press the ◀▶ buttons or turn the dial to choose an image, then press the (FUNC SET) button.
  - ▶ 🔑 will appear on the screen.
- Pressing the (FUNC SET) button again deselects the image and 🔑 will disappear.
- To choose additional images, repeat the above procedure.

3 Protect the image.

- If you press the MENU button, a confirmation screen will appear.
- Press the ◀▶ buttons or turn the dial to choose [OK], then press the (FUNC SET) button.

> If you switch shooting modes or turn off the power before performing the operations in Step 3, images will not be protected.

Select Range

1 Choose [Select Range].

- Follow Step 2 on p. 117 to choose [Select Range], then press the (FUNC SET) button.

2 Choose a starting image.

- Press the (FUNC SET) button.

- Press the ◀▶ buttons or turn the dial to choose an image, then press the (FUNC SET) button.

Downloaded From camera-usermanual.com Canon Manuals

3 Choose an ending image.

- Press the ▶ button to choose [Last image], then press the (FUNC SET) button.

- Press the ◀▶ buttons or turn the dial to choose an image, then press the (FUNC SET) button.
- You cannot choose images before the first image.

4 Protect images.

- Press the ▼ button to choose [Protect], then press the (FUNC SET) button.

Choose images with the dial

You can also choose the first or last image by turning the dial when the upper screen in Steps 2 and 3 is displayed.

Choose All Images

1 Choose [All Images].

- Follow Step 2 on p. 117 to choose [All Images], then press the (FUNC SET) button.



2 Protect images.

- Press the ▲▼ buttons or turn the dial to choose [Protect], then press the (FUNC SET) button.

You can unlock groups of protected images if you choose [Unlock] in Step 4, while in [Select Range] or Step 2 while in [All Images].

Downloaded From camera-usermanual.com Canon Manuals

Erasing Images

You can choose images and then erase them in groups. Since erased images cannot be recovered, exercise adequate caution before erasing. Protected images (p. 117) cannot be erased.

Choose a selection method



1 Choose [Erase].

- Press the MENU button to choose [Erase] in the ▶ tab, then press the (FUNC SET) button.

2 Choose a selection method.

- Press the ▲▼ buttons or turn the dial to choose a selection method, then press the (FUNC SET) button.
- Pressing the MENU button will restore the menu screen.

Choosing Images Individually

1 Choose [Select].

- Follow Step 2 above to choose [Select] and press the (FUNC SET) button.

2 Choose an image.

- If you follow Step 2 on p. 118 to choose images, ✓ will appear on the screen.
- Pressing the (FUNC SET) button again deselects the image and ✓ will disappear.
- To choose additional images, repeat the above procedure.

3 Erase.

- If you press the MENU button, a confirmation screen will appear.
- Press the ◀▶ buttons or turn the dial to choose [OK], then press the (FUNC SET) button.

Downloaded From camera-usermanual.com Canon Manuals

Select Range

1 Choose [Select Range].

- Follow Step 2 on p. 120 to choose [Select Range], then press the (FUNC SET) button.

2 Choose images.

- Follow Steps 2 and 3 on p. 118 to choose images.

3 Erase.

- Press the ▼ button to choose [Erase], then press the (FUNC SET) button.

Choose All Images

1 Choose [All Images].

- Follow Step 2 on p. 120 to choose [All Images], then press the (FUNC SET) button.

2 Erase.

- Press the ◀▶ buttons or turn the dial to choose [OK], then press the (FUNC SET) button.

Downloaded From camera-usermanual.com Canon Manuals

Tagging Images as Favorites

When you tag images as favorites, you can easily categorize just those images. You can also filter out just those images for viewing, protecting or erasing (p. 109).



Make the setting.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose ★, then press the (FUNC SET) button again.
- ▶ [Tagged as favorites] will appear on the screen.
- To untag the image, follow the above Step to choose ★ again, then press the (FUNC SET) button.

Using the Menu

1 Choose [Favorites].

- Press the MENU button to choose [Favorites] in the ▶ tab, then press the (FUNC SET) button.

2 Choose an image.

- Press the ◀▶ buttons or turn the dial to choose an image, then press the (FUNC SET) button.
- ▶ ★ will appear on the screen.
- Pressing the (FUNC SET) button again untags the image and ★ disappears.
- To choose additional images, repeat the above procedure.

3 Make the setting.

- If you press the MENU button, a confirmation screen will appear.
- Press the ◀▶ buttons or turn the dial to choose [OK], then press the (FUNC SET) button.

Downloaded From camera-usermanual.com Canon Manuals

If you switch Shooting modes or turn off the power before making the setting in Step 3, images will not be tagged as favorites.

If you use Windows 7 or Windows Vista and transfer tagged images to the computer, they will be given a star rating of 3 (★ ★ ★ ☆ ☆) (except for movies).

Organizing Images by Category (My Category)

You can organize images into categories. You can display the images in a category in Filtered Playback (p. 109) and process all images at once by using the functions below.

- Viewing Slideshows (p. 110), Protecting Images (p. 117), Erasing All Images (p. 120), Choosing Images for Printing (DPOF) (p. 137)

Images are automatically categorized by shooting condition as they are shot.

: Images with detected faces, or images shot in or mode.
: Images detected as , or in AUTO mode, or images shot in or mode.
: Images shot in , or mode.

1 Choose .

- After pressing the FUNC SET button, press the ▲▼ buttons or turn the dial to choose , then press the FUNC SET button again.

2 Choose a category.

- Press the ▲▼ buttons to choose a category, then press the FUNC SET button.
- ▶ ✓ will appear on the screen.
- Pressing the FUNC SET button again deselects the image and ✓ will disappear.

Downloaded From camera-usermanual.com Canon Manuals

3 Make the setting.

- If you press the MENU button, a confirmation screen will appear.
- Press the ◀▶ buttons or turn the dial to choose [OK], then press the (FUNC SET) button.

If you switch Shooting modes or turn off the power before making the setting in Step 3, images will not be tagged as My Category.

Using the Menu



1 Choose [My Category].

- Press the MENU button to choose [My Category] in the ▶ tab, then press the (FUNC SET) button.



2 Choose a selection method.

- Press the ▲▼ buttons or turn the dial to choose a selection method, then press the (FUNC SET) button.
- Pressing the MENU button will restore the menu screen.

Choosing Images Individually

1 Choose [Select].

- Follow Step 2 above to choose [Select], then press the (FUNC SET) button.

2 Choose an image.

- Press the ◀▶ buttons or turn the dial to choose an image.

3 Choose a category.

- Press the ▲▼ buttons, or turn the dial to choose a category, then press the (FUNC SET) button.

Downloaded From camera-usermanual.com Canon Manuals

▶ ✓ will appear on the screen.
- Pressing the (FUNC SET) button again deselects the image and ✓ will disappear.
- To choose additional images, repeat the above procedure.

4 Make the setting.
- If you press the MENU button, a confirmation screen will appear.
- Press the ◀▶ buttons or turn the dial to choose [OK], then press the (FUNC SET) button.

If you switch Shooting modes or turn off the power before making the setting in Step 4, images will not be tagged as My Category.

Select Range

1 Choose [Select Range].
- Follow Step 2 on p. 124 to choose [Select Range], then press the (FUNC SET) button.

2 Choose images.
- Follow Steps 2 and 3 on p. 118 to choose images.

3 Choose a category.
- Press the ▼ button to choose an item, then press the ◀▶ buttons or turn the dial to choose a category.

4 Choose the setting.
- Press the ▼ button to choose [Select], then press the (FUNC SET) button.

If you choose [Deselect] in Step 4, you can deselect all of the images in the [Select Range] category.

Downloaded From camera-usermanual.com Canon Manuals

Rotating Images

You can change the orientation of an image and save it.

1 Choose .

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose , then press the (FUNC SET) button again.

2 Rotate the image.

- Press the ◀▶ buttons to rotate the image 90° in the chosen direction.
- Press the (FUNC SET) button to make the setting.

Using the Menu



1 Choose [Rotate].

- Press the MENU button to choose [Rotate] in the ▶ tab, then press the (FUNC SET) button.

2 Rotate the image.

- Press the ◀▶ buttons or turn the dial to choose an image.
- ▶ The image will rotate 90° with each press of the (FUNC SET) button.
- Pressing the MENU button will restore the menu screen.

Movies with a resolution of 1920 or 1280 cannot be rotated.

Downloaded From camera-usermanual.com Canon Manuals

Resizing Images

You can resize images to a lower pixel setting and save the resized image as a separate file.

1 Choose [Resize].

- Press the MENU button to choose [Resize] in the ▶ tab, then press the (FUNC SET) button.

2 Choose an image.

- Press the ◀▶ buttons or turn the dial to choose an image, then press the (FUNC SET) button.

3 Choose an image size.

- Press the ◀▶ buttons or turn the dial to choose an option, then press the (FUNC SET) button.
- ▶ The [Save new image?] screen will appear.



4 Save the new image.

- Press the ◀▶ buttons or turn the dial to choose [OK] and press the (FUNC SET) button.
- ▶ The image will be saved as a new file.

5 Display the new image.

- When you press the MENU button, the [Display new image?] screen will appear.
- Press the ◀▶ buttons or turn the dial to choose [Yes], then press the (FUNC SET) button.
- ▶ The saved image will be displayed.

- You cannot resize an image to a larger size.
- Images recorded at a pixel setting of W (p. 74), or saved as XS in Step 3 cannot be edited.

Downloaded From camera-usermanual.com Canon Manuals

Trimming

You can cut out a portion of a recorded image and save it as a new image file.



1 Choose [Trimming].

- Press the MENU button to choose [Trimming] in the ▶ tab, then press the (FUNC SET) button.

2 Choose an image.

- Press the ◀▶ buttons or turn the dial to choose an image, then press the (FUNC SET) button.

Trimming Area



Trimming Area Display

Recorded pixels after trimming

3 Adjust the trimming area.

- ▶ A frame will appear around the portion of the image to be trimmed.
- ▶ The original image will display in the upper left and the trimmed image will display in the lower right.
- If you move the zoom lever to the left or right, you can change the frame size.
- If you press the ▲▼◀▶ buttons, you can move the frame.
- If you press the (FUNC SET) button, you can change the frame orientation.
- In an image with detected faces, gray frames appear around the faces located in the upper left image. The frames can be used for trimming. You can switch between frames by turning the dial.
- Press the MENU button.

4 Save as a new image and display.

- Follow Steps 4 and 5 on p. 127.

Downloaded From camera-usermanual.com Canon Manuals

- Images recorded at a pixel setting of S or W (p. 75), or images resized to XS (p. 127) cannot be edited.
- The width and height ratio of an image that can be trimmed is fixed at 4:3.
- The number of recorded pixels in a trimmed image will be smaller than before trimming.

Adding Effects with the My Colors Function

You can change the color of an image and save it as a separate image. Refer to p. 79 for details on each menu item.



1 Choose [My Colors].

- Press the MENU button to choose [My Colors] in the ▶ tab, then press the (FUNC SET) button.

2 Choose an image.

- Press the ◀▶ buttons or turn the dial to choose an image, then press the (FUNC SET) button.

3 Choose a menu option.

- Press the ◀▶ buttons or turn the dial to choose an option, then press the (FUNC SET) button.

4 Save as a new image and display.

- Follow Steps 4 and 5 on p. 127.

If you repeatedly change the color of the same image, the quality will gradually deteriorate and you may not achieve the expected color.

The color of images changed with this function may vary from those recorded with the My Colors function (p. 79).

Downloaded From camera-usermanual.com Canon Manuals

Correcting the Brightness (i-Contrast)

The camera can detect areas in an image, such as faces or backgrounds, that are too dark and automatically adjust them to the optimum brightness. Also, when the overall image is lacking in contrast, the camera will automatically correct the image for a sharper impression. You can choose from four levels of correction, and save the image as a new file.



1 Choose [i-Contrast].

- Press the MENU button to choose [i-Contrast] in the ▶ tab, then press the (FUNC SET) button.

2 Choose an image.

- Press the ◀▶ buttons or turn the dial to choose an image, then press the (FUNC SET) button.

3 Choose a menu item.

- Press the ◀▶ buttons or turn the dial to choose an option, then press the (FUNC SET) button.

4 Save as a new image and display.

- Follow Steps 4 and 5 on p. 127.

- Under some conditions, the image may appear coarse or not be corrected properly.
- Repeatedly adjusting the same image may cause it to become coarse.

What if the image wasn't corrected by the [Auto] option as well as you would like?

Choose [Low], [Medium] or [High] and adjust the image.

Downloaded From camera-usermanual.com Canon Manuals

Correcting the Red-Eye Effect

You can automatically correct red eyes in images and save them as new files.



1 Choose [Red-Eye Correction].

- Press the MENU button to choose [Red-Eye Correction] in the ▶ tab, then press the (FUNC SET) button.

2 Choose an image.

- Press the ◀▶ buttons or turn the dial to choose an image.

3 Correct the image.

- Press the (FUNC SET) button.
- ▶ Red-eye detected by the camera will be corrected and a frame will appear around the corrected portion.
- You can magnify or reduce the size of the image using the procedures in “Magnifying Images” (p. 113).

4 Save as a new image and display.

- Press the ▲▼◀▶ buttons or turn the dial to choose [New File], then press the (FUNC SET) button.
- ▶ The image will be saved as a new file.
- Follow Step 5 on p. 127.

- Some images may not be corrected properly.
- When [Overwrite] in Step 4 is chosen, the uncorrected image is overwritten with the corrected data, erasing the original image.
- Protected images cannot be overwritten.

Downloaded From camera-usermanual.com Canon Manuals

Downloaded From camera-usermanual.com Canon Manuals

8

Printing

This chapter explains how to choose images for printing, and print using a Canon-brand PictBridge compliant printer (sold separately) (p. 40).

Please also refer to the *Personal Printing Guide*.

Canon-Brand PictBridge Compliant Printers



Downloaded From camera-usermanual.com Canon Manuals

Printing Images

You can easily print the pictures you take by connecting the camera to a PictBridge compliant printer (sold separately) using the supplied interface cable (p. 2).







1 **Turn off the camera and printer.**

2 **Connect the camera to the printer.**

- Open the cover and insert the small plug of the included interface cable (p. 2) firmly into the camera terminal in the direction shown.
- Insert the interface cable's larger plug into the printer. For connection details, refer to the user guide provided with the printer.

3 **Turn on the printer.**

4 **Turn on the camera.**

- Press the ▶ button to turn on the camera.

5 **Choose an image to print.**

- Press the ◀▶ buttons or turn the dial to choose an image.

Downloaded From camera-usermanual.com Canon Manuals

6 Choose 🖨.

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose 🖨, then press the (FUNC SET) button again.

7 Print images.

- Press the ▲▼ buttons or turn the dial to choose [Print], then press the (FUNC SET) button.
- ▶ Printing will start.
- If you want to print additional images, repeat Steps 5 to 7 after printing has completed.
- After printing has completed, turn off the camera and printer, and unplug the interface cable.

- Refer to the *Personal Printing Guide* for details on printing.
- Refer to p. 40 for Canon-brand Pictbridge compliant printers.
- Index printing (p. 137) is not available on certain Canon-brand PictBridge compliant printers (sold separately).

Downloaded From camera-usermanual.com Canon Manuals

Printing from the Print List (DPOF)

You can add images to the print list (DPOF) directly after shooting or during playback in the FUNC. menu.
These selection methods comply with the DPOF (Digital Print Order Format) standards.

1 Choose an image.

- Press the ◀▶ buttons or turn the dial to choose an image.

2 Choose (movies will be excluded).

- After pressing the (FUNC SET) button, press the ▲▼ buttons or turn the dial to choose , then press the (FUNC SET) button again.

3 Add images to the print list.

- Press the ▲▼ buttons to choose the number of prints, then press the ◀▶ buttons or turn the dial to choose [Add] and press the (FUNC SET) button.
- To cancel adding images, repeat Steps 1 and 2, and press the ◀▶ buttons or turn the dial to choose [Remove], then press the (FUNC SET) button.

You cannot add images when the camera is connected to the printer.

Downloaded From camera-usermanual.com Canon Manuals

Choosing Images for Printing (DPOF)

You can choose up to 998 images on a memory card for printing and specify settings such as the number of copies so that they can be printed together (p. 140) or processed at a photo developer service. These selection methods comply with the DPOF (Digital Print Order Format) standards.

Print Settings

You can set the print type, date and file number. These settings apply to all images chosen for printing.



1 Choose [Print Settings].

- Press the MENU button to choose [Print Settings] in the tab, then press the FUNC SET button.

2 Adjust the settings.

- Press the ▲▼ buttons or turn the dial to choose a menu item, then press the ◀▶ buttons to choose an option.
- Pressing the MENU button accepts the settings and restores the menu screen.

Print Type	Standard	Prints one image per page.
	Index	Prints several reduced size images per page.
	Both	Prints both standard and index formats.
Date	On	Prints the shooting date.
	Off	—
File No.	On	Prints the file number.
	Off	—
Clear DPOF data	On	Removes all print settings after printing.
	Off	—

- Some printers or photo developer services may not be able to reflect all of the settings in the prints.
- ! may appear when using a memory card with print settings set by a different camera. These settings will be overwritten with those set by your camera.
- If [Date] is set to [On], some printers may print the date twice.

Downloaded From camera-usermanual.com Canon Manuals

- With [Index] chosen, the [Date] and [File No.] options cannot be set to [On] at the same time.
- The date will be printed in the style set in the [Date/Time] function in the tab (p. 20).
- Movies cannot be added to a print list.

Choosing the Number of Copies

1 Choose [Select Images & Qty.].

- Press the MENU button to choose [Select Images & Qty.] in the tab, then press the (FUNC SET) button.

2 Choose an image.

- Press the ◀▶ buttons or turn the dial to choose an image, then press the (FUNC SET) button.
- ▶ You will be able to set the number of print copies.
- If you choose images in [Index], ✓ appears on the screen. Pressing the (FUNC SET) button again will deselect the image and ✓ will disappear.

3 Set the number of prints.

- Press the ▲▼ buttons or turn the dial to set the number of prints (maximum 99).
- Repeat Steps 2 and 3 to choose other images and the number of prints for each.
- You cannot set the number of copies for index prints. You can only choose which images to print (as shown in Step 2).
- Pressing the MENU button accepts the settings and restores the menu screen.

Downloaded From camera-usermanual.com Canon Manuals

Select Range

1 Choose [Select Range].

- In Step 1 on p. 138, choose [Select Range], then press the (FUNC SET) button.
- Follow Steps 2 and 3 on p. 118 to choose images.

2 Make print settings.

- Press the ▲▼ buttons to choose [Order], then press the (FUNC SET) button.

Set All Images to Print Once

1 Choose [Select All Images].

- In Step 1 on p. 138, choose [Select All Images], then press the (FUNC SET) button.

2 Make print settings.

- Press the ◀▶ buttons or turn the dial to choose [OK], then press the (FUNC SET) button.

Clearing All Selections

1 Choose [Clear All Selections].

- In Step 1 on p. 138, choose [Clear All Selections], then press the (FUNC SET) button.



2 All selections will be cleared.

- Press the ◀▶ buttons or turn the dial to choose [OK], then press the (FUNC SET) button.

Downloaded From camera-usermanual.com Canon Manuals

Print Added Images

You can print images added to the print list by connecting the camera to a PictBridge compliant printer (pp. 136 – 139).

1 Connect the camera to the printer.

- Follow Steps 1 to 4 on p. 134.

2 Print.

- Press the ▲▼ buttons to choose [Print now], then press the (FUNC SET) button.
- ▶ Printing will start.
- If you stop the printer during printing and start again, it will start from the next print.

Downloaded From camera-usermanual.com Canon Manuals

9

Customizing Camera Settings

You can customize various settings to suit your shooting preferences. The first part of this chapter explains convenient and commonly used functions.
The latter part explains how to change shooting and playback settings to suit your purposes.

Downloaded From camera-usermanual.com Canon Manuals

Changing Camera Settings

You can customize convenient and commonly used functions from the 🔧 tab (p. 47).

Changing Sounds

You can change each of the camera's operation sounds.



- Choose [Sound Options], then press the (FUNC SET) button.
- Press the ▲▼ buttons or turn the dial to choose an option.
- Press the ◀▶ buttons to choose an option.

1	Preset sounds (cannot be modified)
2	Preset sounds You can use the included software to change the sounds (p. 2).

Turning Off Hints & Tips

When you choose an item in the FUNC. menu (p. 46) or MENU (p. 47), a description of the function (hints and tips) is displayed. You can turn off this function.

- Choose [Hints & Tips], then press the ◀▶ buttons to choose [Off].

Downloaded From camera-usermanual.com Canon Manuals

Changing the Start-up Screen

You can change the start-up screen that appears when you turn on the camera.



- Choose [Start-up Image], then press the (FUNC SET) button.
- Press the ◀▶ buttons or turn the dial to choose an option.

☐×	No start-up image
1	Preset images (cannot be modified)
2	Preset images You can set recorded images, and use the included software to change the images.

Registering Recorded Images as the Start-up Screen

When you press the ▶ button and set the camera to Playback mode, you can register an image.

- Choose [Start-up Image], then press the (FUNC SET) button.
- Press the ◀▶ buttons or turn the dial to choose [2], then press the (FUNC SET) button.
- Press the ◀▶ buttons or turn the dial to choose an image, then press the (FUNC SET) button.
- Press the ◀▶ buttons or turn the dial to choose [OK], then press the (FUNC SET) button to complete registration.

Any previously registered start-up image will be overwritten when registering a new start-up image.

Downloaded From camera-usermanual.com Canon Manuals

Register the start-up image or sounds with the included software

The dedicated operation sounds and start-up images on the included software can be registered to the camera. Refer to the *Software Guide* for details.

Changing the File Number Assignment

Images you shoot are automatically assigned file numbers in the order they were taken, from 0001 – 9999, and saved to folders of up to 2,000 images. You can change the file number assignment.

- Choose [File Numbering], then press the ◀▶ buttons to choose an option.

Continuous	Even if you shoot using a new memory card, the file numbers are assigned consecutively until an image with the number 9999 is taken/saved.
Auto Reset	If you replace the memory card with a new one, or a new folder is created, file numbering begins with 0001 again.

- If you use a memory card already containing images, the newly assigned file numbers may continue the existing numbering for both [Continuous] and [Auto Reset]. If you want to start over with file number 0001, format the memory card before use (p. 23).
- Refer to the *Software Guide* for information regarding folder structure or image types.

Creating Folders by Shooting Date

Images are saved into folders created each month, however, you can also create folders by shooting date.



- Choose [Create Folder], then press the ◀▶ buttons to choose [Daily].
- Images will be saved into folders created on each shooting date.

Downloaded From camera-usermanual.com Canon Manuals

Changing the Lens Retract Time

For safety reasons, the lens retracts about 1 minute after pressing the ▶ button when in a Shooting mode (p. 28). If you want the lens to retract immediately when you press the ▶ button, set the retract time to [0 sec.].



- Choose [Lens Retract], then press the ◀▶ buttons to choose [0 sec.].

Turning Off the Power Saving Function

You can set the power saving function (p. 51) to [Off]. Setting it to [On] is recommended to save battery power.

- Choose [Power Saving], then press the FUNC SET button.
- Press the ▲▼ buttons or turn the dial to choose [Auto Power Down], then press the ◀▶ buttons to choose [Off].
- If you set the power saving function to [Off], be sure to turn the camera off after use.

Setting the Screen Shut-Off Time

You can adjust the time the screen takes to shut off automatically (p. 51). This also works when [Auto Power Down] is set to [Off].

- Choose [Power Saving], then press the FUNC SET button.
- Press the ▲▼ buttons or turn the dial to choose [Display Off], then press the ◀▶ buttons to choose a time.
- In order to save battery power, you should choose less than [1 min.].

Downloaded From camera-usermanual.com Canon Manuals

Using the World Clock

When traveling abroad, you can record images with local dates and times simply by switching the time zone setting. If you pre-register the destination time zones, you can enjoy the convenience of not having to switch the Date/Time settings.



1 Set the home time zone.

- Choose [Time Zone], then press the (FUNC SET) button.
- When setting this for the first time, check the information that displays on the screen at the left, then press the (FUNC SET) button.
- Press the ◀▶ buttons or turn the dial to choose the home time zone.
- To set daylight saving time (adds 1 hour), press the ▲▼ buttons to choose ☀.
- Press the (FUNC SET) button.





2 Set the world time zone.

- Press the ▲▼ buttons or turn the dial to choose [✈ World], then press the (FUNC SET) button.
- Press the ◀▶ buttons or turn the dial to choose the destination time zone.
- You can also set the daylight saving time as in Step 1.
- Press the (FUNC SET) button.



3 Choose the world time zone.

- Press the ▲▼ buttons or turn the dial to choose ✈, then press the MENU button.

▶ ✈ will appear on the shooting screen (p. 162).

Downloaded From camera-usermanual.com Canon Manuals

If you change the date or time in the setting (p. 20), your [Home] time and date will automatically change.

Changing Shooting Function Settings

If you set the mode switch to , and the mode to **P**, you can change the settings in the tab (p. 47).

Before attempting to shoot using a function explained in this chapter in modes other than **P** mode, check if the function is available in those modes (pp. 166 – 169).

Switching the Focus Setting

The camera focuses on whatever it is aimed at even when the shutter button is not pressed. However, you can set it so that the camera only focuses when the shutter button is pressed halfway.

- Choose [Continuous AF], then press the ◀▶ buttons to choose [Off].

On	Since the camera focuses continuously until you press the shutter button halfway, it allows you to shoot without missing photo opportunities.
Off	The camera does not focus continuously, thereby conserving battery power.

Turning Off the AF Assist Beam

The lamp will automatically light to assist focusing in low light conditions when you press the shutter button halfway. You can turn off the lamp.



- Choose [AF-assist Beam], then press the ◀▶ buttons to choose [Off].

Downloaded From camera-usermanual.com Canon Manuals

Turning Off the Red-Eye Reduction Function

The red-eye reduction lamp lights in order to reduce the red-eye effect that occurs when shooting in dark conditions with the flash. You can turn off this function.



- Choose [Flash Settings], then press the (FUNC SET) button.
- Press the ▲▼ buttons or turn the dial to choose [Red-Eye Lamp], then press the ◀▶ buttons to choose [Off].

Changing the Image Display Time Right After Shooting

You can change the length of time the images display right after shooting.

- Choose [Review], then press the ◀▶ buttons to choose an option.

2 – 10 sec.	Displays images for the set time.
Hold	The image displays until you press the shutter button halfway.
Off	Images will not display.

Downloaded From camera-usermanual.com Canon Manuals

Changing the Way the Image Displays Right After Shooting

You can change the way the image displays right after shooting.



- Choose [Review Info], then press the ◀▶ buttons to choose an option.

Off	Displays the image only.
Detailed	Displays detailed information (p. 164).
Focus Check	The area inside the AF frame is magnified, allowing you to check the focus. The procedure is the same as in “Checking the Focus” (p. 112).

Displaying the Overlay

You can display gridlines for vertical and horizontal guidance, or a 3:2 guide to confirm the printable area for postcard size prints.



- Choose [Disp. Overlay], then press the ◀▶ buttons to choose an option.

Grid Lines	A grid overlays the screen.
3:2 Guide	Gray bars appear on the top and bottom of the screen. This area will not print when printing on paper with a 3:2 aspect ratio.
Both	Both grid lines, and the 3:2 guide appear.

- In W, you cannot set [3:2 Guide] or [Both].
- Grid lines will not be recorded on the image.
- The gray areas displayed with [3:2 Guide] are the areas that will not be printed. The actual image recorded will include the portion in the gray areas.

Downloaded From camera-usermanual.com Canon Manuals

Changing the IS-Mode Settings



- Choose [IS Mode], then press the ◀▶ buttons to choose an option.

Continuous	Image stabilization is always on. You can confirm the effects directly on the display, which makes it easier to check the composition or focus. When shooting movies, the camera also reduces strong camera shake, for example when walking (Dynamic mode).
Shoot Only*	Image stabilization is only active at the moment of shooting.
Panning*	Image stabilization only counters up and down motion. This option is recommended for shooting objects moving horizontally.

* Setting changes to [Continuous] when shooting movies.

- If camera shake is too strong, attach the camera to a tripod. You should also set the IS Mode to [Off] when the camera is attached to a tripod.
- When using [Panning], hold the camera horizontally to shoot. Image stabilization does not work when the camera is held vertically.

When shooting movies, if you press the zoom lever toward W and zoom out, the effect increases.

Downloaded From camera-usermanual.com Canon Manuals

Changing Playback Function Settings

You can adjust the settings in the ▶ tab by pressing the ▶ button (p. 47).

Choosing the Image that First Displays in Playback



- Choose [Resume], then press the ◀▶ buttons to choose an option.

Last seen	Resumes with the image last viewed.
Last shot	Resumes with the most recently shot image.

Downloaded From camera-usermanual.com Canon Manuals

Downloaded From camera-usermanual.com Canon Manuals

10

Useful Information

This chapter introduces how to use the AC adapter kit and Eye-Fi card (both sold separately), troubleshooting tips, and contains lists of functions and items that appear on the screen.

Downloaded From camera-usermanual.com Canon Manuals

Using Household Power

If you use AC Adapter Kit ACK-DC70 (sold separately), you can use the camera without worrying about how much charge is left in the battery.

1 Turn off the camera.



2 Insert the coupler.

- Follow Step 1 on p. 17 to open the cover, then insert the coupler as shown until it locks into place with a click.
- Follow Step 3 on p. 17 to close the cover.



3 Plug the cord into the coupler.

- Open the cover and fully insert the plug into the coupler.



4 Connect the power cord.

- Connect the power cord to the compact power adapter, then plug the other end into a power outlet.
- Turn the camera on to use it.
- After you finish, turn off the camera and unplug the power cord from the power outlet.

Do not unplug the plug or power cord with the camera turned on. This could erase images you have taken or damage the camera.

Downloaded From camera-usermanual.com Canon Manuals

Using an Eye-Fi Card

Before using an Eye-Fi card, be sure to check whether Eye-Fi card use is authorized in the country or territory of use (p. 16).

When you put a prepared Eye-Fi card into the camera, you can automatically transfer your images wirelessly to a computer, or upload them to a web service.
Image transfer is a function of the Eye-Fi card. For details on how to setup and use the card, and concerning problems transferring images, please refer to the Eye-Fi card user guide, or contact the manufacturer.

Please keep the following things in mind when using an Eye-Fi card.

- Even if you set [Eye-Fi trans.] to [Disable] (p. 156), the Eye-Fi card may transmit radio waves. Be sure to remove the Eye-Fi card from the camera before entering areas that prevent unauthorized transmission of radio waves, such as hospitals and airplanes.
- If you have trouble transferring images, check the card or computer settings. For details, refer to the user guide supplied with the card.
- Depending on the connection status of the wireless network, it may take time to transfer images, or image transfer may be interrupted.
- Due to its transfer function, the Eye-Fi card may become hot.
- Battery consumption will be quicker than in normal use.
- Camera operations will be slower than in normal use. This may be resolved by setting [Eye-Fi trans.] to [Disable].

If you put an Eye-Fi card into the camera, the connection status can be checked in the shooting screen (Information Display) and playback screen (Simple Information Display).

(Gray)	Not connected
(Flashing white)	Connecting
(White)	Transfer standby
(Animated)	Transferring
	Interrupted
	Error retrieving Eye-Fi card info (Turn the camera off and on again. If this continues to appear, there may be a problem with the card.)

will appear on transferred images.

The power saving function does not work while transferring images (p. 51).

Downloaded From camera-usermanual.com Canon Manuals

Checking Connection Information

You can check the Eye-Fi card's access point SSID, or connection status.



Choose [Connection info].

- Press the MENU button, then choose [Eye-Fi Settings] from the tab, and press the (FUNC SET) button.
- Press the ▲▼ buttons or turn the dial to choose [Connection info], then press the (FUNC SET) button.

▶ The Connection info screen will appear.

Disabling Eye-Fi Transfer

You can set the card to disable Eye-Fi transfer.



Choose [Disable] in [Eye-Fi trans.].

- Press the MENU button to choose [Eye-Fi Settings] from the tab, then press the (FUNC SET) button.
- Press the ▲▼ buttons or turn the dial to choose [Eye-Fi trans.], then press the ◀▶ buttons to choose [Disable].

What if [Eye-Fi Settings] does not appear?

[Eye-Fi Settings] will only appear when an Eye-Fi card is inserted in the camera.

If the Eye-Fi card has a write-protect tab, you will not be able to check the card's connection status, or set [Eye-Fi trans.] to [Disable] when the tab is in the locked position.

Downloaded From camera-usermanual.com Canon Manuals

Troubleshooting

If you think there is a problem with the camera, first check the following. If the items below do not solve your problem, contact a Canon Customer Support Help Desk as listed on the included customer support list.

Power

You pressed the ON/OFF button, but nothing happened.

- Confirm that the battery is the correct type, and is not depleted (p. 15).
- Confirm that the battery is properly inserted (p. 17).
- Confirm that the memory card/battery cover is securely closed (pp. 17, 18).
- If the battery terminals are dirty, battery performance will decrease. Clean the terminals with a cotton swab and re-insert the battery several times.

Battery is consumed quickly.

- Battery performance decreases at low temperatures. Warm the battery, for example, by placing it in your pocket with the terminal cover on.

Lens will not retract.

- Do not open the memory card/battery cover while the power is on. After closing the memory card/battery cover, turn the power on then back off (pp. 17, 18).

TV output

Image is distorted or not showing on TV (p. 115).

Shooting

Cannot shoot.

- When in Playback mode (p. 22), press the shutter button halfway (p. 24).

The screen is off (p. 157).

Screen does not display properly in dark places (p. 45).

Screen does not display properly while shooting.

Please note, the following will not be recorded in still images, but will be recorded in movies.

- When the camera is subjected to powerful light sources, the display may darken.
- When shooting under fluorescent or LED lighting, the screen may flicker or horizontal lines may appear across the screen.
- When shooting bright light sources, a bar of light (purplish red) may appear on the screen.

A flashing ϟ appears on the screen and the shot cannot be taken even though the shutter button was pressed fully (p. 27).

appears when the shutter button is pressed halfway (p. 56).

- Set the [IS mode] to [Continuous] (p. 150).
- Set the flash to ϟ (p. 73).
- Increase the ISO speed (p. 76).
- Attach the camera to a tripod. Additionally, you should set the [IS Mode] to [Off] when shooting with a tripod (p. 150).

Downloaded From camera-usermanual.com Canon Manuals

Image is blurred.

- Press the shutter button halfway to focus on the subject, then press fully to shoot (p. 24).
- Shoot the subject within the focusing distance (p. 172).
- Set the [AF-assist Beam] to [On] (p. 147).
- Confirm that functions which you do not intend to use (macro, etc.) are not set.
- Shoot using the focus lock or AF lock (pp. 82, 86).

Even when you press the shutter button halfway, the AF frame does not appear, and the camera does not focus.

- If you center on the light and dark contrasting area of the subject and push the shutter button halfway, or repeatedly push the shutter button halfway, the AF frame will appear and the camera will focus.

Subject is too dark.

- Set the flash to ϟ (p. 73).
- Correct the brightness with exposure compensation (p. 72).
- Adjust the image with i-Contrast (pp. 90, 130).
- Use AE Lock, or spot metering to shoot (pp. 87, 88).

Subject is too bright (overexposed).

- Set the flash to ⊗ (p. 56).
- Correct the brightness with exposure compensation (p. 72).
- Use AE Lock, or spot metering to shoot (pp. 87, 88).
- Reduce the light illuminating the subject.

Image is dark even though the flash fired (p. 27).

- Shoot within an appropriate distance for flash photography (p. 73).
- Increase the ISO speed (p. 76).

Image taken using the flash is too bright (overexposed).

- Shoot within an appropriate distance for flash photography (p. 73).
- Set the flash to ⊗ (p. 56).

White dots appear on the image when shooting with the flash.

- Light from the flash has reflected off dust particles or other objects in the air.

Image appears rough or grainy.

- Shoot with the ISO speed on a lower setting (p. 76).
- Depending on the Shooting mode, when shooting in a high ISO speed the image may appear rough or grainy (pp. 62, 63).

Eyes appear red (p. 90).

- Set the [Red-Eye Lamp] to [On] (p. 148). When shooting with the flash, the lamp (on the front of the camera) lights (p. 42), and for approximately 1 second while the camera is reducing red-eye, it is not possible to shoot. It is more effective if the subject is looking directly at the lamp. Even better results can be obtained by increasing the lighting in indoor settings or approaching closer to the subject.

Downloaded From camera-usermanual.com Canon Manuals

Recording images to the memory card takes a long time, or continuous shooting slows down.

- Perform a low-level format of the memory card in the camera (p. 52).

Cannot make settings for shooting functions or FUNC. menu.

- The items in which settings can be made differ depending on the shooting mode. Refer to “Functions Available in Each Shooting Mode” and “Shooting Menu” (pp. 166 – 169).

Shooting movies

Correct shooting time does not display, or stops.

- Format the memory card in the camera, or use a memory card capable of recording at high speeds. Even when the shooting time does not display properly, the recorded video will be the length that it was actually shot (pp. 23, 31).

! appeared on the screen and shooting ended automatically.

The camera’s internal memory was insufficient. Try one of the following:

- Perform a low-level format of the memory card in the camera (p. 52).
- Change the movie quality setting (p. 101).
- Use a memory card capable of recording at high speeds (p. 101).

Subject appears distorted.

- The subject may appear distorted if it passes quickly in front of the camera while shooting. This is not a malfunction.

Playback

Cannot play back images or movies.

- If the file name or folder structure is changed on a computer, you may not be able to play back images or movies. Refer to the *Software Guide* for information regarding folder structure or file names.

Playback stops, or audio cuts out.

- Use a memory card that has had a low-level format performed on it with this camera (p. 52).
- If you copy a movie to a memory card that reads slowly, playback may interrupt momentarily.
- Depending on its capabilities, when playing movies on a computer, frames may drop or the audio may cut out.

Computer

Cannot transfer images to a computer.

It may be possible to solve the problem when the camera is connected to a computer via cable by reducing the transfer speed.

- Press the ▶ button to enter Playback mode. Then press and hold the MENU button and press the ▲ and (FUNC SET) buttons together. In the screen that appears, press the ◀▶ buttons to choose [B] and press the (FUNC SET) button.

Eye-Fi Card

Cannot transfer images (p. 155).

Downloaded From camera-usermanual.com Canon Manuals

List of Messages That Appear on the Screen

If error messages appear on the screen, try one of the following solutions.

No memory card

- The memory card is not installed in the correct direction. Install the memory card in the correct direction (p. 18).

Memory card locked

- The SD memory card, SDHC memory card, SDXC memory card or Eye-Fi card's write protect tab is set to "LOCK". Unlock the write protect tab (pp. 18, 19).

Cannot record!

- You attempted to shoot an image without a memory card. Install the memory card in the correct direction to shoot (p. 18).

Memory card error (p. 52)

- If the same message appears even when a formatted memory card is installed in the correct direction, contact a Canon Customer Support Help Desk (p. 18).

Insufficient space on card

- There is not enough free space on the memory card to shoot (pp. 25, 30, 55, 71, 98) or edit images (pp. 127 – 131). Erase the images (pp. 29, 120) to open space for new images, or insert an empty memory card (p. 18).

Change the battery pack. (p. 15)

No Image.

- There are no images recorded on the memory card that can be displayed.

Protected! (p. 117)

Unidentified Image/Incompatible JPEG/Image too large./Cannot play back AVI/RAW

- Unsupported images, or images with corrupted data cannot be displayed.
- Images manipulated on a computer, that have had their file name changed, or have been taken with a different camera may not display.

Cannot magnify!/Cannot play back this content in Smart Shuffle/Cannot rotate/Cannot modify image/Cannot register this image!/Cannot modify/Cannot assign to category/Unselectable image.

- Incompatible images cannot be magnified (p. 113), played back in Smart Shuffle (p. 113), tagged as favorites (p. 122), rotated (p. 126), edited (pp. 127 – 131), registered to the start-up screen (p. 143), categorized (p. 123), or added to a print list (p. 136).
- Images manipulated on a computer, that have had their file name changed, or have been taken with a different camera may not be magnified, played back in Smart Shuffle, tagged as favorites, rotated, edited, registered to the start-up screen, categorized, or added to a print list.
- Movies cannot be magnified (p. 113), played back in Smart Shuffle (p. 113), edited (pp. 127 – 131), added to a print list (pp. 136, 137), or registered to the start-up screen (p. 143).

Downloaded From camera-usermanual.com Canon Manuals

Invalid selection range

- When choosing the selection range (pp. 118, 121, 125, 139), you tried to choose a starting image that was after the last image or you tried to choose an ending image that was before the starting image.

Exceeded selection limit

- You chose more than 998 images in print settings. Choose less than 998 images (p. 138).
- Print settings could not be saved correctly. Reduce the number of selected images and try again (p. 138).
- You chose 501 or more images in Protect (p. 117), Erase (p. 120), Favorites (p. 122), My Category (p. 123) and Print Settings (pp. 136, 138).

Communication error

- Images could not be transferred to the computer or printed due to the large amount of images (approx. 1000) stored on the memory card. Use a commercially available USB card reader to transfer the images. Insert the memory card into the printer's card slot to print.

Naming error!

- The folder or image could not be created because there is an image with the same file name as the folder or image that the camera is attempting to create, or the highest possible file number has already been reached. In the menu, change [File Numbering] to [Auto Reset] (p. 144) or format the memory card (p. 23).

Lens Error

- This error can occur if you hold the lens while it is in motion or when using it in a location with excessive dust or sand in the air.
- If this error message continues to appear, contact a Canon Customer Support Help Desk as there may be a problem with the lens.

A camera error was detected (Error number)

- If an error code appears directly after taking a picture, the shot may not have been recorded. Check the image in Playback mode.
- If this error code reappears, note the Error number (Exx) and contact a Canon Customer Support Help Desk as there may be a problem with the camera.

Downloaded From camera-usermanual.com Canon Manuals

Information Displayed on the Screen

Shooting (Information Display)



① Battery Charge Indicator (p. 15)
② Camera Orientation*
③ White Balance (p. 77)
④ My Colors (p. 79)
⑤ Drive Mode (p. 78)
⑥ Camera shake warning (p. 27)
⑦ Metering Method (p. 87)
⑧ Image Quality (Compression) (p. 74) / Recording Pixels (p. 74)
⑨ Still Images: Recordable Shots (pp. 15, 75)
⑩ Eye-Fi Connection Status (p. 155)
⑪ Movie Quality (p. 101)
⑫ Movies: Remaining Time (pp. 31, 101)
⑬ AF Frame (p. 84)
⑭ Spot AE Point Frame (p. 87)
⑮ Digital Zoom Magnification (p. 57) / Digital Tele-converter (p. 58)
⑯ Focusing Range (p. 73), AF Lock (p. 86)
⑰ Shooting Mode (p. 166), Scene Icon (p. 163)
⑱ Flash Mode (pp. 56, 73, 89)
⑲ Red-Eye Correction (p. 131)
⑳ Date Stamp (p. 59)
㉑ ISO Speed (p. 76)
㉒ Self-Timer (pp. 60, 80, 81, 66)
㉓ Disp. Overlay (p. 149)
㉔ AE Lock (p. 88), FE Lock (p. 88)
㉕ Shutter Speed
㉖ Aperture Value
㉗ Exposure Compensation Amount (p. 72)
㉘ i-Contrast (p. 90)
㉙ Super Slow Motion Movie Elapsed Time (p. 99)
㉚ Zoom Bar (p. 25)
㉛ Blink Detection (p. 91)
㉜ Time Zone (p. 146)
㉝ Image Stabilizer (p. 150)
㉞ Exposure Shift Bar

* : Standard, : Held vertically
When shooting, the camera detects if it is held vertically or horizontally, and adjusts settings accordingly for the best shot. It also detects orientation during playback, so you can hold the camera in either orientation and it will automatically rotate images for correct viewing.
This function may not operate correctly when the camera is pointed straight up or down.

Downloaded From camera-usermanual.com Canon Manuals

Scene Icons

In AUTO mode, the camera displays an icon for the scene it has determined and then automatically focuses and selects the optimum settings for subject brightness and color.

Subject / Background	People	When Moving	With Strong Facial Shadows	Non-Human Subjects/ Landscapes	Close Subjects	Icon Background Color
Bright						Gray
Backlit			—			
Including Blue Skies						Light Blue
Backlit			—			
Sunsets	—				—	Orange
Spotlights						Dark Blue
Dark						
When Using Tripod	*	—		*	—	

* Appears when the scene is dark and the camera is attached to a tripod.

Downloaded From camera-usermanual.com Canon Manuals

Playback (Detailed Information Display)



① Print List (pp. 136, 137)
② My Category (p. 123)
③ Shooting mode (p. 166)
④ ISO Speed (p. 76), Playback Speed (Movies) (p. 99)
⑤ Exposure Compensation (p. 72), Exposure Shift Amount (p. 102)
⑥ White Balance (p. 77)
⑦ Histogram (p. 45)
⑧ Compression (Image Quality) (p. 74) / Recording Pixels (p. 74), MOV (Movies)
⑨ Eye-Fi Transfer Complete (p. 155)
⑩ Battery Charge Indicator (p. 15)
⑪ Metering Method (p. 87)
⑫ Folder Number – File Number (p. 144)
⑬ Displayed image number / Total number of images
⑭ Shutter Speed, Movie Quality, Frame Rate (Movies) (p. 101)
⑮ Aperture Value
⑯ Flash (p. 73)
⑰ i-Contrast (pp. 90, 130)
⑱ Focusing Range (p. 73)
⑲ File Size (pp. 75, 101)
⑳ Still Images: Recording Pixels (p. 74)
Movies: Movie Length (p. 101)
㉑ Image Editing (pp. 127 – 131)
㉒ Protect (p. 117)
㉓ Favorites (p. 122)
㉔ My Colors (pp. 79, 129)
㉕ Red-Eye Correction (pp. 90, 131)
㉖ Shooting Date and Time (p. 20)

Downloaded From camera-usermanual.com Canon Manuals

Handling Precautions

- This camera is a high-precision electronic device. Do not drop it or subject it to strong impacts.
- Never place the camera close to magnets, motors or other devices that generate strong electromagnetic fields. Exposure to strong magnetic fields may cause malfunctions or corrupt image data.
- If water droplets or dirt become stuck on the camera or screen, wipe with a dry soft cloth or eyeglass wiper. Do not rub or apply force.
- Never use cleaners containing organic solvents to wipe the camera or screen.
- Use a commercially available blower brush to remove dust from the lens. For stubborn dirt contact a Canon Customer Support Help Desk as listed in your Warranty System Booklet.
- When you move the camera rapidly from cold to hot temperatures, condensation may form on the internal or external surfaces of the camera. To avoid condensation, put the camera in an airtight, resealable plastic bag and let it adjust to temperature changes slowly before removing it from the bag.
- If condensation has formed on the camera, stop using it immediately, as continued use may damage the camera. Remove the battery and memory card, and wait until the moisture has completely evaporated before resuming use.

Downloaded From camera-usermanual.com Canon Manuals

Functions Available in Each Shooting Mode

Function \ Shooting modes		AUTO	P					
Self-Timer (pp. 60, 66, 80, 81)		O	O	O	O	—	—	—
		O	O	O	O	—	—	—
AE Lock/Exposure Shift (p. 102)		—	—	—	—	—	—	—
AE Lock/FE Lock (p. 88)		—	O	—	—	—	—	—
Flash (pp. 56, 73, 89)		O	O	O	O	O	O	O
		—	O	O	O	O	O	O
		*2	O	—	—	—	—	—
		O	O	O	O	O	O	O
Focusing Range (p. 73)		—	O	—	—	—	—	—
		O	O	O	O	O	O	O
		—	O	—	—	—	—	—
AF Lock (p. 86)		—	O	—	—	—	—	—

FUNC. Menu								
Metering Method (p. 87)		O	O	O	O	O	O	O
		—	O	—	—	—	—	—
My Colors (p. 79)		O	O	O	O	O	O	O
		—	O	—	—	—	—	—
White Balance (p. 77)		O	O	O	O	O	O	O
		—	O	—	—	—	—	—
ISO Speed (p. 76)		O	O	O	O	O	O	O
		—	O	—	—	—	—	—
Exposure Compensation (p. 72)		—	O	O	O	O	O	O
Drive Mode (p. 78)		O	O	O	O	—	—	—
		—	O	O	O	—	—	—
		—	O	O	O	—	—	—
Recording Pixels (p. 74)	L M1 M2 S W	O	O	O	O	O	O	O
Movie Quality (p. 101)	1920 1280 640 320	O	O	O	O	O	O	O
Compression Ratio (p. 74)		O	O	O	O	O	O	O

*1 The number of shots cannot be specified, and the time delay cannot be set to 0 seconds.
*2 Not selectable but switches to depending on the circumstances.
*3 Not selectable but switches to when the flash fires.
*4 White Balance data not recordable.
*5

Downloaded From camera-usermanual.com Canon Manuals

—	—	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
—	—	○	○	○	○	★1	★1	★1	○	○	○	○	○	★1	★1	★1	★1	★1	★1
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	—	—	—	—
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
—	—	—	○	○	○	○	○	○	○	○	○	○	—	—	—	—	—	—	—
—	—	—	—	○	○	○	○	○	○	○	○	○	—	○	○	—	—	—	—
—	—	—	—	—	—	—	—	—	—	—	—	—	—	★3	○	—	—	—	—
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—	—	—
○	—	—	—	—	—	○	—	—	—	—	—	—	—	○	○	○	○	—	○
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
○	—	—	—	—	—	○	—	—	—	—	—	—	—	○	○	○	○	—	○
—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	—	○	—	—	—

FUNC. Menu

○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
—	—	—	—	—	—	—	—	—	—	—	—	—	○	○	○	—	—	—	—
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
○	—	—	○	—	—	—	—	—	—	—	—	—	○	★4	○	—	—	—	—
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
○	—	○	○	○	—	—	○	○	○	○	○	○	—	○	—	—	—	—	—
—	—	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—	—	—	—
○	○	—	○	○	○	○	○	○	○	○	○	○	—	—	—	—	—	—	—
—	—	—	○	○	○	○	○	○	○	○	○	★5	—	—	—	—	—	—	—
★6	★6	★7	★6	○	○	○	○	○	○	○	○	○	○	★8	○	○	○	○	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	★9	★10	○	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	

*6 Recording pixels are fixed to M.
*7 Fixed to L.
*8 Recording pixel setting W not selectable.
*9 Fixed to 320.
*10 1920 or 320 is not available.

○ Selectable, or set automatically. – Not selectable

Downloaded From camera-usermanual.com Canon Manuals

Shooting Menu

Function	Shooting Modes		AUTO	P					
AF Frame (p. 84)	Face Detect		*1	O	O	O	O	O	O
	Center		—	O	O	O	—	—	—
AF Frame Size (p. 85)	Normal/Small		—	O	—	—	—	—	—
Digital Zoom (p. 57)	Standard		O	O	O	O	O	O	O
	Off		O	O	O	O	O	O	O
	Digital Tele-converter (1.4x/2.3x)		O	O	O	O	O	O	O
AF-Point Zoom (p. 85)	On/Off		O	O	O	—	O	O	O
Servo AF (p. 86)	On/Off		*3	O	O	*4	—	—	—
Continuous AF (p. 147)	On/Off		*4	O	O	—	*4	*4	*4
AF-assist Beam (p. 147)	On/Off		O	O	O	O	*4	O	O
Flash Settings (pp. 90, 148)	Red-Eye Corr.	On/Off	O	O	O	O	O	O	O
	Red-Eye Lamp	On/Off	O	O	O	O	O	O	O
i-Contrast (p. 90)	Auto/Off		*5	O	—	—	—	—	—
Review (p. 148)	Off/2 – 10 sec./Hold		O	O	O	O	O	O	O
Review Info (p. 149)	Off/Detailed/Focus Check		O	O	O	O	O	O	O
Blink Detection (p. 91)	On/Off		O	O	O	O	O	O	O
Disp Overlay (p. 149)	Grid Lines		O	O	O	O	O	O	O
	3:2 Guide		O	O	O	O	O	O	O
IS Mode (p. 150)	Continuous/Off		*6	O	O	O	O	O	O
	Shoot Only/Panning		—	O	O	O	O	O	O
Date Stamp (p. 59)	Off/Date/Date & Time		O	O	O	O	O	O	O

*1 9 points when a face is not detected.
*2 Only available for shooting still images.
*3 [On] when movement is detected.
*4 Fixed to [On].
*5 Fixed to [Auto].
*6 Fixed to [Continuous].

Downloaded From camera-usermanual.com Canon Manuals

O	O	O	*1	O	O	O	—	—	O	O	O	—	O	—	*2	*2	—	*2
O	—	—	O	O	O	O	O	—	O	O	O	O	O	O	*2	*2	—	*2
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
—	—	—	—	O	O	—	—	—	O	O	O	O	O	—	O	—	—	—
O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
—	—	—	—	O	O	—	—	—	O	O	O	O	O	—	—	—	—	—
O	O	—	O	O	O	O	—	—	O	O	O	—	O	—	—	—	—	—
—	—	—	O	O	O	O	—	—	O	O	O	—	—	—	—	—	—	—
*4	*4	O	—	O	O	O	O	O	O	O	O	—	O	O	*4	*4	*4	*4
O	O	O	O	O	O	O	O	O	O	O	O	—	O	O	O	O	O	O
—	—	—	O	O	O	—	—	—	O	O	O	—	O	—	—	—	—	—
—	—	—	O	O	O	O	O	O	O	O	O	—	O	O	—	—	—	—
*5	*5	—	*5	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	—	—	—	—
O	O	O	O	O	O	O	O	O	O	O	O	O	O	—	—	—	—	—
—	—	—	O	O	O	O	—	—	O	O	O	—	—	—	—	—	—	—
O	O	O	O	O	O	O	O	O	O	O	O	O	O	—	O	O	O	O
O	O	O	O	O	O	O	O	O	O	O	O	O	O	—	—	—	—	—
O	O	*6	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
O	O	—	O	O	O	O	O	O	O	O	O	O	O	O	—	—	—	—
—	—	—	—	O	O	O	O	O	O	O	O	O	O	—	—	—	—	—

O Selectable, or set automatically. – Not selectable

Downloaded From camera-usermanual.com Canon Manuals

Set up Menu

Item	Content	Ref. Page
Mute	On/Off*	p. 48
Volume	Set all operation sounds (5 levels).	p. 48
Sound Options	Set the sounds for each camera operation.	p. 142
Hints & Tips	On*/Off	p. 142
LCD Brightness	Set within a range of ±2.	p. 49
Start-up Image	Add an image as a start-up image.	p. 143
Format	Formats memory card, erasing all data	pp. 23, 52
File Numbering	Continuous*/Auto Reset	p. 144
Create Folder	Monthly*/Daily	p. 144
Lens Retract	1 min.*/0 sec.	p. 145
Power Saving	Auto Power Down: On*/Off Display Off: 10, 20 or 30 sec./1*, 2 or 3 min.	pp. 51, 145
Time Zone	Home*/World	p. 146
Date/Time	Date and time settings	p. 21
Video System	NTSC* / PAL	p. 115
Eye-Fi Settings	Eye-Fi connection settings (only appears when Eye-Fi card is inserted)	p. 155
Language	Choose display language.	p. 22
Reset All	Returns camera to default settings.	p. 50

* Default setting

Print Menu

Item	Content	Ref. Page
Print	Displays printing screen (When connected to a printer).	—
Select Images & Qty.	Chooses individual images for printing.	p. 138
Select Range	Chooses starting and ending images for printing.	p. 139
Select All Images	Chooses all images for printing.	p. 139
Clear All Selections	Cancels all settings for printing.	p. 139
Print Settings	Sets the printing style.	p. 137

Downloaded From camera-usermanual.com Canon Manuals

Playback Menu

Item	Content	Ref. Page
Slideshow	Plays back images automatically.	p. 110
Erase	Erases images (Select, Select Range, All Images)	p. 120
Protect	Protects images (Select, Select Range, All Images)	p. 117
Rotate	Rotates images.	p. 126
Favorites	Tags or untags images as favorites.	p. 122
My Category	Categorizes images (Select, Select Range)	p. 123
i-Contrast	Corrects dark portions and contrast in still images.	p. 130
Red-Eye Correction	Corrects red eyes in still images.	p. 131
Trimming	Trims portions of still images.	p. 128
Resize	Resizes and saves still images.	p. 127
My Colors	Adjusts colors in still images.	p. 129
Scroll Display	On*/Off	p. 108
Resume	Last seen*/Last shot	p. 151
Transition	Fade*/Scroll/Slide/Off	p. 114

* Default setting

Playback Mode FUNC. Menu

Item	Content	Ref. Page
Rotate	Rotates displayed image.	p. 126
Print List	Selects or clears settings for printing displayed image. (Print appears when the camera is connected to the printer)	p. 136
Protect	Protects/unlocks displayed image.	p. 117
Favorites	Tags/untags displayed image as favorites.	p. 122
Erase	Erases displayed image.	p. 120
Play Movie	Starts Play Movie.	p. 32
Smart Shuffle	Starts Smart Shuffle.	p. 113
Filtered Playback	Filters/cancels filter for displayed image.	p. 109
Slideshow	Plays back images automatically.	p. 110
My Category	Categorizes images.	p. 123

Downloaded From camera-usermanual.com Canon Manuals

Specifications

Image Sensor	
Camera Effective Pixels	Approx. 10 million pixels
Lens	
Focal Length	10x zoom: 6.3 (W) – 63.0 (T) mm (35mm film equivalent: 36 (W) – 360 (T) mm)
Focusing Range	1 cm (0.4 in.) – infinity (W), 1 m (3.3 ft.) – infinity (T) • Macro: 1 – 50 cm (0.4 in. – 1.6 ft.) (W)
Image Stabilizer (IS) System	Lens-shift type
Imaging Processor	DIGIC 4
LCD Monitor	
Type	TFT color (wide viewing angle type)
Size	7.6 cm (3.0 in.)
Effective Pixels	Approx. 230,000 dots
Aspect Ratio	16:9
Function	Brightness adjustment (5 levels), Quick-bright LCD
Focus	
Control System	Autofocus: Single (Continuous in Auto mode), Continuous Servo AF (Servo AE)
AF Frame	Face Detect, Center
Metering Method	Evaluative, Center-weighted average, Spot
Exposure Compensation (Still Images) /Exposure Shift (Movies)	2 stops in 1/3-stop increments
ISO Speed (Standard Output Sensitivity, Recommended Exposure Index)	Auto, ISO 125/200/400/800/1600/3200
White Balance	Auto, Day Light, Cloudy, Tungsten, Fluorescent, Fluorescent H, Custom
Shutter Speeds	1 – 1/4000 sec. 15 – 1/4000 sec. (Total shutter speed range)
Aperture	
Type	Blade (x2)
f/number	f/3.4 – f/7.1 (W), f/5.6 – f/9.0 (T)
Flash	
Flash Mode	Auto, on, Slow Synchro, off
Range	30 cm – 3.5 m (W), 1.0 – 2.0 m (T) (12 in. – 12 ft. (W), (3.3 – 6.6 ft. (T))
Shooting Mode	Auto, P, Portrait, Kids&Pets, Smart Shutter*1, High-speed Burst, Best Image Selection, Handheld NightScene, Low Light, Super Vivid, Poster Effect, Color Accent, Color Swap, Fish-eye Effect, Miniature Effect, Beach, Foliage, Snow, Fireworks, Long Shutter, Stitch Assist, Movie*2 *3 *1 Smile, Wink Self-timer, Face Self-timer *2 Smart Auto available *3 Standard, Super Slow Motion, Miniature Effect, Color Accent, Color Swap

Downloaded From camera-usermanual.com Canon Manuals

Digital Zoom	Still images/Movies: Approx. 4x (up to approx. 40x in combination with the optical zoom) Safety Zoom, Digital Tele-converter
Continuous Shooting	
Modes	Normal, AF, LV
Speed (Normal)	Approx. 3.7 shots/sec. (In P mode) Approx. 8.8 shots/sec. (In High-speed Burst mode)
Number of Possible Shots (CIPA compliant)	Approx. 150 shots
Recording Media	SD memory card, SDHC memory card, SDXC memory card, MultiMediaCard, MMC*plus* card, HC MMC*plus* card
File Format	Design rule for Camera File system, DPOF (Version 1.1) compliant
Data Type	
Still Images	Exif 2.3 (JPEG)
Movies	MOV (Image data: H.264, Audio data: Linear PCM (stereo))
Recording Pixels	
Still images	Large: 3648 x 2736, Medium 1: 2816 x 2112, Medium 2: 1600 x 1200, Small: 640 x 480, Widescreen: 3648 x 2048 • Fixed to 1824 x 1368 when in High-speed Burst, Best Image Selection, and Low Light
Movies	Smart Auto, Standard, Color Accent, Color Swap: 1920 x 1080 (24 fps*1), 1280 x 720 (30 fps*1), 640 x 480 (30 fps*1), 320 x 240 (30 fps*2) Super Slow Motion: 320 x 240 (240 fps*3 when shooting, 30 fps*2 during playback) Miniature Effect: 1280 x 720 (Shooting: 6 fps/3 fps/1.5 fps, Playback: 30 fps*2), 640 x 480 (Shooting: 6 fps/3 fps/1.5 fps, Playback: 30 fps*2) *1 Actual frame rate is 23.976 fps. *2 Actual frame rate is 29.97 fps. *3 Actual frame rate is 239.76 fps.
Interface	Hi-Speed USB HDMI output Analog audio output (stereo) Analog video output (NTSC/PAL)
Direct Print Standard	PictBridge
Power	Battery Pack NB-9L AC Adapter Kit ACK-DC70
Dimensions (CIPA compliant)	101.3 x 58.5 x 22.3 mm (3.99 x 2.30 x 0.88 in.)
Weight (CIPA compliant)	Approx. 190 g (6.70 oz.) (Including the battery and memory card) Approx. 167 g (5.89 oz.) (camera body only)

Downloaded From camera-usermanual.com Canon Manuals

Battery Pack NB-9L

Type	Rechargeable lithium-ion battery
Nominal Voltage	3.5 V DC
Nominal Capacity	870 mAh
Battery Life (Charge Cycles)	Approx. 300 times
Operating Temperatures	0 – 40 °C (32 – 104 °F)
Dimensions	14.6 x 43.1 x 15.3 mm (0.57 x 1.70 x 0.60 in.)
Weight	Approx. 21 g (0.74 oz.)

Battery Charger CB-2LB/CB-2LBE

Regions	CB-2LB: Japan/Americas CB-2LBE: Europe/Asia/Oceania
Rated Input	100 V – 240 V (50/60 Hz) 8.5 VA (100 V) – 12 VA (240 V) 0.085 A (100 V) – 0.05 A (240 V)
Rated Output	4.2 V, 0.7 A
Charging Time	Approx. 1 hour and 50 min. (when using NB-9L)
Charge Indicator	Charging: Orange, Fully charged: Green Two indicator system
Operating Temperatures	0 – 40 °C (32 – 104 °F)
Dimensions	82.0 x 59.0 x 24.5 mm (Protrusion: 26.4 mm) (3.23 x 2.32 x 0.96 in. (Protrusion:1.04 in.))
Weight	CB-2LB: Approx. 73 g (2.57 oz.) CB-2LBE: Approx. 67 g (2.36 oz.) (excluding power cord)

- All data is based on tests by Canon.
- Camera specifications or appearance are subject to change without notice.

Downloaded From camera-usermanual.com Canon Manuals

Index

Numerics

3:2 Guide 149

A

AC Adapter Kit 39, 154
Accessories 39
AE Lock 88, 102
AF → Focus
  AF Frames 26, 84
  AF Lock 86, 162
AFB Mode 162
AF-Point Zoom 85
AUTO Mode (Shooting Mode) 25
AV Cable 115

B

Battery
  Battery Charger 14
  Charge Indicator 15
  Date/Time Battery 21
  Power Saving 51, 145
  Recharge 14
Battery Charger 2, 39
Beach (Shooting Mode) 62
Best Image Selection 68
Black and White Images 79
Blink Detection 91

C

Camera
  Default Settings 50
  Holding the Camera 13
Camera Shake 27, 56, 150
Center (AF Frame Mode) 84
Clock Functions 51
Color Accent (Shooting Mode) 92, 98
Color Swap (Shooting Mode) 93, 98
Components Guide 42
Compression (Image Quality) 74
Continuous Shooting 78
  AF 78
  Best Image Selection 68
  High-speed Burst 67
  LV 78

D

Date and Time → Date/Time
Date/Time
  Adding to Image 59
  Changing 21
  Date/Time Battery 21
  Setting 20
  World Clock 146
Default Settings 50
DIGITAL CAMERA Solution Disk 2
Digital Tele-Converter 58
Digital Zoom 57
Display Language 22
DPOF 136, 137
Drive Mode 78
Dynamic Mode 150

E

Editing
  i-Contrast 130
  My Colors 129
  Red-Eye Correction 131
  Resizing (Making Images Smaller) .. 127
  Trimming 128
Erasing Images 29, 120
Error Messages 160
Exposure
  AE Lock 88, 102
  Correction 72
  FE Lock 88
  Shift 102
Eye-Fi Card 16, 155

F

Face Detect (AF Frame Mode) 84
Face Self-Timer (Shooting Mode) 66
Factory Settings → Default Settings
FE Lock 88, 162
File Numbering 144
Filtered Playback 109
Fireworks (Shooting Mode) 63
Fish-eye Effect (Shooting Mode) 69
Flash
  Off 56

Downloaded From camera-usermanual.com Canon Manuals

On ... 73
Slow Synchro ... 89
Focus
AF Frame ... 26, 84
AF Lock ... 86
AF-Point Zoom ... 85
Servo AF ... 86
Focus Check ... 112
Focus Lock ... 82
Foliage (Shooting Mode) ... 62
Format → Memory Cards, Formatting
Formatting (Memory Card) ... 23, 52
FUNC. Menu
List ... 171
Menu ... 46

G

Grid Lines ... 149, 162

H

Handheld NightScene (Shooting Mode) ... 62
High-speed Burst ... 67
Household Power ... 154

I

i-Contrast ... 90, 162
Image Quality → Compression Ratio
Images
Display Time ... 148
Editing → Editing
Erasing Images ... 29, 120
Playback → Viewing
Protect ... 117
Included Items → Accessories
Indicator ... 43, 45
Interface Cable ... 2, 35, 134
ISO Speed ... 76, 162

K

Kids&Pets (Shooting Mode) ... 61

L

Lamp ... 42, 147, 148
LCD Monitor (Screen) ... 3
LCD Monitor → Screen
Long Shutter (Shooting Mode) ... 95
Low Light (Shooting Mode) ... 62

M

Magnified Display ... 113
Manual White Balance ... 77
Memory Cards ... 16
Available Shots ... 19, 75
Formatting ... 23, 52
Shooting Time ... 31, 101
Memory Cards → Card
Menu
Basic Operations ... 47
List ... 168
Metering Method ... 87
Miniature Effect (Movie Mode) ... 99
Miniature Effect (Shooting Mode) ... 70
Movies
Editing ... 105
Modes ... 98
Movie Quality (Recording Pixels/ Frame Rate) ... 101
Shooting Time ... 15, 101
Viewing (Playback) ... 32, 104
MultiMediaCard/MMCplus → Memory Cards
My Category ... 123
My Colors ... 79

P

P (Shooting mode) ... 72
Personal Printing Guide ... 2
PictBridge ... 40, 134
Playback → Viewing
Playback With Transition Effects ... 114
Portrait (Shooting Mode) ... 61
Poster Effect (Shooting Mode) ... 63
Power → Battery, AC Adapter Kit
Power Saving ... 51, 145
Printing ... 134
Program AE ... 72
Protect ... 117

Downloaded From camera-usermanual.com Canon Manuals

R

Recording Pixels (Image Size) 74
Red-Eye Correction 90, 131
Resizing (Making Images Smaller) 127
Rotate 126

S

Screen
- Display Language 22
- Information Display 162, 164
- Menu → FUNC. Menu, Menu
- Switching the Display 44

SD/SDHC/SDXC Memory Card → Memory Cards
Self-Timer
- 10 Second Self-Timer 60
- Changing Delay and Number of Shots 81
- Face Self-Timer (Shooting Mode) 66
- Two Second Self-Timer 80
- Wink Self-Timer (Shooting Mode) 65

Sepia Tones 79
Servo AF 86
Shooting
- Display Overlay 149
- Number of Shots 15, 19, 75
- Shooting Date and Time → Date/Time
- Shooting Info 162
- Shooting Time 31, 101

Shooting Using a TV 82
Slideshow 110
Smart Shuffle 113
Smile (Shooting Mode) 64
Snow (Shooting Mode) 63
Software
- DIGITAL CAMERA Solution Disk 2
- Installation 34
- Software Guide 2
- Transferring Images to a Computer for Viewing 33

Sound Settings 48
Stereo AV Cable 2, 115
Stitch Assist (Shooting Mode) 96
Strap 13
Super Slow Motion (Movie Mode) 99
Super Vivid (Shooting Mode) 63

T

Tag Images as Favorites 122
Terminal 35, 115, 116, 134, 154
Travel Abroad 15, 39, 146
Trimming 128
Troubleshooting 157

V

Video → Movies
Viewing
- Filtered Playback 109
- Images on a TV 115, 116
- Index Display 108
- Magnified Display 113
- Single Image Playback 28
- Slideshow 110
- Smart Shuffle 113

Viewing Images on a TV 115, 116

W

White Balance 77
Wide (Recording Pixels) 74, 75
Wink Self-Timer (Shooting Mode) 65
World Clock 146

Z

Zoom 25, 30, 57

Downloaded From camera-usermanual.com Canon Manuals

Disclaimer

- Reprinting, transmitting, or storing in a retrieval system any part of this guide without the permission of Canon is prohibited.
- Canon reserves the right to change the contents of this guide at any time without prior notice.
- Illustrations and screenshots in this guide may differ slightly from the actual equipment.
- The above items notwithstanding, Canon accepts no liability for damages due to mistaken operation of the products.

© CANON INC. 2010
Downloaded From camera-usermanual.com Canon Manuals